

eZMP-Synqnet Quick Start Guide

Quick Start



Contents

Introduction
Safety Warnings

Connecting to the eZMP

Setting up the eZMP
 Direct Connection via Crossover Cable
 Network Connection via LAN
 Standalone Operation
eZMP Startup
 Inserting the Compact Flash
 Connecting Power
Enable UPnP on the Host System
Remote Desktop to the eZMP

Software Installation

Software on the eZMP
Software on the Host System

Setting Up the SynqNet Network

Choose SynqNet Network Topology
SynqNet Cable Connections

[<< Return to eZMP-Synqnet Documentation](#)