

SqNode Objects

Introduction

A **SqNode** object manages a single SynqNet network node connected to a SynqNet network. It represents the physical network node. It contains information about the node, as well as its status and configuration. It provides read/write access to the node via network cyclic data and service commands. It also provides an interface to any drives connected to the node.

During network initialization, the SynqNet nodes are discovered and mapped to the SynqNet object. The number of motors per SqNode is determined and mapped to the controller's motor objects. Each node connected to a controller is assigned a number (0, 1, 2, etc) in the order it is discovered. The node number is used to index the SqNode objects.

Methods

Create, Delete, Validate Methods

[meiSqNodeCreate](#)

[meiSqNodeDelete](#)

[meiSqNodeValidate](#)

Configuration and Information Methods

[meiSqNodeCommand](#)

[meiSqNodeConfigGet](#)

[meiSqNodeConfigSet](#)

[meiSqNodeFlashConfigGet](#)

[meiSqNodeFlashConfigSet](#)

[meiSqNodeFpgaDefaultFileName](#)

[meiSqNodeInfo](#)

[meiSqNodeStatus](#)

[meiSqNodeUserDataGet](#)

[meiSqNodeUserDataSet](#)

Drive Interface Methods

[meiSqNodeDriveConfigGet](#)

[meiSqNodeDriveConfigSet](#)

[meiSqNodeDriveInfo](#)

[meiSqNodeDriveMapParamCount](#)

[meiSqNodeDriveMapParamList](#)

[meiSqNodeDriveMapConfigCount](#)

[meiSqNodeDriveMapConfigList](#)

[meiSqNodeDriveMapParamFileGet](#)

[meiSqNodeDriveMapParamFileSet](#)

[meiSqNodeDriveMonitor](#)

[meiSqNodeDriveMonitorConfigGet](#)

[meiSqNodeDriveMonitorConfigSet](#)

[meiSqNodeDriveParamCalculate](#)

[meiSqNodeDriveParamClear](#)

[meiSqNodeDriveParamGet](#)

[meiSqNodeDriveParamListGet](#)

[meiSqNodeDriveParamListSet](#)

[meiSqNodeDriveParamReload](#)

[meiSqNodeDriveParamRestore](#)

[meiSqNodeDriveParamSet](#)

[meiSqNodeDriveParamStore](#)

I/O Methods

[meiSqNodeAnalogIn](#)

[meiSqNodeAnalogOutGet](#)

[meiSqNodeAnalogOutSet](#)

[meiSqNodeDigitalIn](#)

[meiSqNodeDigitalOutGet](#)

[meiSqNodeDigitalOutSet](#)

[meiSqNodeSegmentAnalogIn](#)

[meiSqNodeSegmentAnalogOutGet](#)

[meiSqNodeSegmentAnalogOutSet](#)

[meiSqNodeSegmentInfo](#)

[meiSqNodeSegmentDigitalIn](#)

[meiSqNodeSegmentDigitalOutGet](#)

[meiSqNodeSegmentDigitalOutSet](#)

[meiSqNodeSegmentUserDataGet](#)

[meiSqNodeSegmentUserDataSet](#)

Action Methods

[meiSqNodeDownload](#)

[meiSqNodeFlashErase](#)

[meiSqNodeFpgaFileNameVerify](#)

[meiSqNodeStatusClear](#)

[meiSqNodeVerify](#)

Event Methods

[meiSqNodeEventNotifyGet](#)

[meiSqNodeEventNotifySet](#)

[meiSqNodeEventReset](#)

Memory Methods

[meiSqNodeMemory](#)

[meiSqNodeMemoryGet](#)

[meiSqNodeMemorySet](#)

Relational Methods

[meiSqNodeControl](#)

[meiSqNodeNumber](#)

Data Types

[MEISqNodeCallback](#)

[MEISqNodeChannel](#)

[MEISqNodeCmdHeader](#)

[MEISqNodeCmdType](#)

[MEISqNodeCommand](#)

[MEISqNodeConfig](#)

[MEISqNodeConfigIoAbort](#)

[MEISqNodeConfigAlarm](#)

[MEISqNodeConfigPacketError](#)

[MEISqNodeConfigTrigger](#)

[MEISqNodeConfigUserFault](#)

[MEISqNodeDataSize](#)

[MEISqNodeDownloadParams](#)

[MEISqNodeDriveInfo](#)

[MEISqNodeDriveMonitor](#)

[MEISqNodeDriveMonitorConfig](#)

[MEISqNodeDriveMonitorData](#)

[MEISqNodeDriveMonitorDataType](#)

[MEISqNodeDriveParamCallback](#)

[MEISqNodeDriveParamCallbackType](#)

[MEISqNodeFeedbackSecondary](#)

[MEISqNodeFileName](#)

[MEISqNodeFpgaType](#)

[MEISqNodeInfo](#)

[MEISqNodeInfoId](#)

[MEISqNodeInfoIo](#)

[MEISqNodeInfoFpga](#)

[MEISqNodeInfoNetwork](#)

[MEISqNodeMemory](#)

[MEISqNodeMessage](#)

[MEISqNodeMonitorValue](#)

[MEISqNodeMonitorValueIndex](#)

[MEISqNodeResponse](#)

[MEISqNodeSegmentInfo](#)

[MEISqNodeSegmentUserData](#)

[MEISqNodeStatus](#)

[MEISqNodeStatusCrcError](#)

[MEISqNodeStatusPacketError](#)

[MEISqNodeUserData](#)

Constants

[MEISqNodeID_CHAR_MAX](#)

[MEISqNodeFILENAME_MAX](#)

[MEISqNodeManufacturerDATA_CHAR_MAX](#)

[MEISqNodeMaxFEEDBACK_SECONDARY](#)

[MEISqNodeMaxMOTORS](#)

[MEISqNodeNOT_AVAILABLE](#)

[MEISqNodeSTATUS_NOT_AVAILABLE](#)

[MEISqNodeUserData_CHAR_MAX](#)

[MEISqNodeSegmentInfoMANUFACTURER_LENGTH](#)

[MEISqNodeSegmentInfoMODEL_NAME_LENGTH](#)

[MEISqNodeSegmentInfoSERIAL_NUMBER_LENGTH](#)

[MEISqNodeSegmentUserData_CHAR_MAX](#)

[MEIDriveMapParamMAX_STRING_LENGTH](#)

[MEIFPGARINCONREV](#)

[MEIFpgaSqMACVersionDEFAULT](#)

[MEIFpgaSqMACVersionMIN](#)

[MEIFpgaSqMACVersionMAX](#)

[MEIFpgaSqNodeVersionDEFAULT](#)

[MEIFpgaSqNodeVersionMIN](#)

[MEIFpgaSqNodeVersionMAX](#)

meiSqNodeCreate

Declaration

```
MEISqNode meiSqNodeCreate(MPIControl control,
                           long number)
```

Required Header: stdmei.h

Description

meiSqNodeCreate creates a SqNode object identified by ***number***, which is associated with a control object.

SqNodeCreate is the equivalent of a C++ constructor.

control	a handle to a Control object
number	an index to the SqNode. The first node number is 0, the second is 1, etc.

Return Values

handle	to a SqNode object. After creating a SqNode object it must be validated using <code>meiSqNodeValidate()</code> .
MPIHandleVOID	if the object could not be created

See Also

[meiSqNodeDelete](#) | [meiSqNodeValidate](#)

meiSqNodeDelete

Declaration

```
long meiSqNodeDelete(MEISqNode node);
```

Required Header: stdmei.h

Description

meiSqNodeDelete deletes a SqNode object and invalidates its handle.

SqNodeDelete is the equivalent of a C++ destructor.

node	a handle of the SqNode object to delete in the reverse order to avoid memory leaks.
-------------	---

Return Values

MPIMessageOK	if <i>SqNodeDelete</i> successfully deleted the object.
---------------------	---

See Also

[meiSqNodeCreate](#) | [meiSqNodeValidate](#)

meiSqNodeValidate

Declaration

```
long meiSqNodeValidate(MEISqNode node);
```

Required Header: stdmei.h

Description

meiSqNodeValidate validates a SqNode object and its handle.

SqNodeValidate is the equivalent of a C++ constructor.

node	a handle to a SynqNet node object.
-------------	------------------------------------

Return Values

MPIMessageOK	if <i>SqNode</i> is a handle to a valid object.
---------------------	---

See Also

[meiSqNodeCreate](#) | [meiSqNodeDelete](#)

meiSynqNetCommand

Declaration

```
long meiSqNodeCommand(MEISqNode node ,
                     MEISqNodeCommand *command ,
                     MEISqNodeResponse *response ) ;
```

Required Header: stdmei.h

Description

meiSqNodeCommand sends a service command to a SynqNet node using the data from the structure pointed to by command and writes the response into the structure pointed to by response. Service commands occur across the SynqNet network through a service channel. In SYNQ mode there is one service channel for each node. In ASYNQ mode there is one service channel for all nodes. The controller sends the command and waits for a response using a 4 state handshake. In SYNQ mode the service command data is sent through the cyclic packets, but due to the handshaking, it is not considered a cyclic operation.

For SynqNet nodes that have drive memory interfaces, service commands can be sent to drives. Also, the service commands supports access to drive data memory, program memory, I/O memory, and direct commands. Please see the `MEISqNodeCommand{.}` and `MEISqNodeResponse{.}` structures for more information. And be sure to consult the drive's header file in the (C:\MEI)\XMP\sqNodeLib\include directory, as well as, the drive manufacturer's manual for valid drive addresses.

node	a handle to a SynqNet node object
*command	a pointer to a SynqNet node command structure
*response	a pointer to a SynqNet node response structure

Return Values	
MPIMessageOK	if <i>SqNodeCommand</i> successfully sends a service command and receives a response.
MPIMessageARG_INVALID	if the command pointer is NULL or the response pointer is NULL
MEISynqNetMessageRESPONSE_TIMEOUT	if the node does not respond to the service command.
MEISynqNetMessageREADY_TIMEOUT	if the node is busy and does not acknowledge the service command.

See Also

[MEISqNodeCommand](#) | [MEISqNodeResponse](#) | [MEISqNodeCmdHeader](#) | [MEISqNodeCmdType](#) | [MEISqNodeDataSize](#) | [MEISqNodeMemory](#) | [MEISqNodeChannel](#)

meiSqNodeConfigGet

Declaration

```
long meiSqNodeConfigGet ( MEISqNode node ,
                          MEISqNodeConfig *config ) ;
```

Required Header: stdmei.h

Description

meiSqNodeConfigGet reads a SynqNet node's (*node*) configuration and writes it into the structure pointed to by *config*.

node	a handle to a SynqNet node object.
*config	a pointer to a SynqNet node config structure.

Return Values

MPIMessageOK	if <i>SqNodeConfigGet</i> successfully reads the node configuration.
---------------------	--

See Also

[meiSqNodeInfo](#) | [meiSqNodeDriveConfigGet](#)

meiSqNodeConfigSet

Declaration

```
long meiSqNodeConfigSet ( MEISqNode node ,
                          MEISqNodeConfig *config ) ;
```

Required Header: stdmei.h

Description

meiSqNodeConfigSet writes a SynqNet node's (*node*) configuration using data from the structure pointed to by *config*.

node	a handle to a SynqNet node object
*config	a pointer to a SynqNet node config structure

Return Values

MPIMessageOK	if <i>SqNodeConfigGet</i> successfully writes the node configuration.
MEIMessageARG_INVALID	if the upStreamError or downStreamError fault/fail limits are less than 0 or greater than 255.
MEISqNodeMessageFEEDBACK_MAP_INVALID	if secondary encoder (n) is not mappable to the motor on the node specified by MEISqNodeFeedbackSecondary[n].motorIndex..

See Also

[meiSqNodeInfo](#) | [meiSqNodeDriveConfigSet](#) | [meiSynqNetFlashTopologySave](#)

meiSqNodeFlashConfigGet

Declaration

```
long meiSqNodeFlashConfigGet ( MEISqNode      node ,
                               void              *flash ,
                               MEISqNodeConfig *config ) ;
```

Required Header: stdmei.h

Description

meiSqNodeFlashConfigGet reads a SynqNet node's flash configuration and writes it into the structure pointed to by ***config***.

node	a handle to a SynqNet node object.
*flash	<i>flash</i> is either an MEIFlash handle or MPIHandleVOID. If <i>flash</i> is MPIHandleVOID, an MEIFlash object will be created and deleted internally.
*config	a pointer to a SynqNet node config structure.

Return Values

MPIMessageOK

if *SqNodeFlashConfigGet* successfully reads a SynqNet node's flash configuration and writes it into the structure pointed to by *config*.

See Also

[meiSqNodeFlashConfigSet](#)

meiSqNodeFlashConfigSet

Declaration

```
long meiSqNodeFlashConfigSet(MEISqNode node,
                             void *flash,
                             MEISqNodeConfig *config);
```

Required Header: stdmei.h

Description

meiSqNodeFlashConfigSet sets a SynqNet Node (*node*) flash configuration using data from the structure pointed to by *config*.

NOTE: The network topology must first be saved before changing node config values in Flash memory. These values will also be cleared when network topology is cleared using [meiSynqNetFlashTopologyClear\(.\)](#).

node	a handle to a SynqNet node object.
*flash	<i>flash</i> is either an MEIFlash handle or MPIHandleVOID. If <i>flash</i> is MPIHandleVOID, an MEIFlash object will be created and deleted internally. If <i>flash</i> is a valid MEIFlash handle, then the MEIFlash object cache will be updated, but the actual write to controller flash will not occur. Use meiFlashMemoryFromFileType(...) to prompt the actual write to <i>flash</i> .
*config	a pointer to a SynqNet node config structure.

Return Values

MPIMessageOK	if <i>SqNodeFlashConfigSet</i> successfully sets a SynqNet Node (<i>node</i>) flash configuration using data from the structure pointed to by <i>config</i> .
MEISqNodeMessageFEEDBACK_MAP_INVALID	given secondary encoder (<i>n</i>) is not mappable to the motor on the node specified by <code>MEISqNodeFeedbackSecondary[n].motorIndex</code> .
MPIMessageARG_INVALID	If the <code>upStreamError</code> or <code>downStreamError</code> fault/fail limits are less than 0 or greater than 255.

MEIFlashMessageNETWORK_TOPOLOGY_ERROR

if a valid flash handle was supplied and SynqNet topology had not yet been saved to flash using `meiSynqNetFlashTopologySave()`.

See Also

[meiSqNodeFlashConfigGet](#) | [Flash Objects](#) | [meiSynqNetFlashTopologySave](#)

meiSqNodeFpgaDefaultFileName

Declaration

```
long meiSqNodeFpgaDefaultFileName( MEISqNode      sqNode ,
                                   MEISqNodeFileName *fileName ) ;
```

Required Header: stdmei.h

Description

meiSqNodeFpgaDefaultFileName provides the default image filename for an sqNode.

sqNode	handle to a SqNode object.
*fileName	a pointer to a structure that has space allocated to hold an FPGA filename.

Return Values

MPIMessageOK	if <i>SqNodeFpgaDefaultFileName</i> successfully returns the name of an FPGA image file.
MPIMessageARG_INVALID	if the pointer to filename is NULL

See Also

meiSqNodeInfo

Declaration

```
long meiSqNodeInfo(MEISqNode node,
                  MEISqNodeInfo *info);
```

Required Header: stdmei.h

Description

meiSqNodeInfo reads a SynqNet node's information and writes it into a structure pointed to by *info*. The info structure contains read only data about the node.

The RMB-10V, RMB-10V2 and some Trust nodes support analog inputs. MPI support has been added to support the reading of node-based analog inputs. The number of analog inputs a node supports can be determined with `meiSqNodeInfo(...)`. An analog input value can be read with [meiSqNodeAnalogIn\(...\)](#). The analog to digital converted value is scaled from -1.0 to +1.0, where +1.0 is a full-scale positive voltage. The input range of the ADC is hardware-specific.

node	a handle to a SynqNet node object.
*info	a pointer to a drive specific information structure.

Return Values

MPIMessageOK	if <i>SqNodeInfo</i> successfully reads the node information.
MPIMessageARG_INVALID	if the info pointer is NULL.

See Also

[meiSqNodeDriveInfo](#) | [meiSqNodeConfigGet](#) | [meiSqNodeDriveConfigGet](#)

meiSqNodeStatus

Declaration

```
long meiSqNodeStatus(MEISqNode node,
                    MEISqNodeStatus *status);
```

Required Header: stdmei.h

Description

meiSqNodeStatus reads status from the *node* associated with the SynqNet object and writes it into the structure pointed to by *status*. The SynqNet node status structure contains error counters and event mask data.

NOTE: This data requires service commands to access the data on the node. As a result, it may take up to 9 servo cycles to read the data. At the default sample rate of 2kHz, this would translate to 4.5ms.

node	a handle to a SynqNet node object.
*status	pointer to a SynqNet status structure.

Return Values

MPIMessageOK	if <i>SynqNetStatus</i> successfully reads the node status and writes it into the structure.
MPIMessageARG_INVALID	if the status pointer is NULL.

See Also

[meiSynqNetStatus](#) | [meiSqNodeInfo](#)

meiSqNodeUserDataGet

Declaration

```
long meiSqNodeUserDataGet(MEISqNode node,
                          MEISqNodeUserData *data);
```

Required Header: stdmei.h

Description

meiSqNodeUserDataGet reads the user data from the node.

node	a handle to a SynqNet node object.
*data	a pointer to a MEISqNodeUserData structure, allocated on the host.

Return Values

MPIMessageOK	if <i>SqNodeUserDataGet</i> successfully gets the user data from the node.
---------------------	--

See Also

[meiSqNodeUserDataSet](#)

meiSqNodeUserDataSet

Declaration

```
long meiSqNodeUserDataSet(MEISqNode node,
                          MEISqNodeUserData *data);
```

Required Header: stdmei.h

Description

meiSqNodeUserDataSet writes the user data to the node.

node	a handle to a SynqNet node object.
*data	a pointer to a MEISqNodeUserData structure, allocated on the host.

Return Values

MPIMessageOK	if <i>SqNodeUserDataSet</i> successfully sets the user data to the node.
---------------------	--

See Also

[meiSqNodeUserDataGet](#) | [MEISqNodeUserData](#)

meiSqNodeDriveConfigGet

Declaration

```
long meiSqNodeDriveConfigGet(MEISqNode node,
                             long driveIndex, /* relative to the node */
                             void *config); /* node specific */
```

Required Header: stdmei.h

Description

meiSqNodeDriveConfigGet reads a SynqNet node's drive configuration and writes it into a drive specific structure pointed to by **config**. SynqNet nodes may support one or more drive interfaces. The drive configuration can be read if the drive interface hardware supports a communication channel to the drive processor. The drive interface(s) for a SynqNet node are indexed by a number (0, 1, 2, etc.).

The drive configuration structure is drive specific. The SqNodeLib includes the drive specific structures and methods. Please see the drive's header file in the (C:\MEI)\XMP\sqNodeLib\include directory, as well as, the drive manufacturer's documentation for details. Use `meiSqNodeInfo(...)`, to determine if the SynqNet node supports a drive interface and its type.

node	a handle to a SynqNet node object
driveIndex	an index to a drive interface on a SynqNet node. The first drive interface is 0, the second is 1, etc.
*config	a pointer to a drive specific configuration structure.

Return Values

MPIMessageOK	if <i>SqNodeDriveConfigGet</i> successfully reads the drive configuration.
---------------------	--

See Also

[meiSqNodeInfo](#) | [meiSqNodeDriveInfo](#) | [meiSqNodeConfigGet](#)

meiSqNodeDriveConfigSet

Declaration

```
long meiSqNodeDriveConfigSet(MEISqNode node,
                             long driveIndex, /* relative to the node */
                             void *config); /* node specific */
```

Required Header: stdmei.h

Description

meiSqNodeDriveConfigSet writes a SynqNet node's drive configuration from a drive specific structure pointed to by **config**. SynqNet nodes may support one or more drive interfaces. The drive configuration can be written if the drive interface hardware supports a communication channel to the drive processor. The drive interface(s) for a SynqNet node are indexed by a number (0, 1, 2, etc.).

The drive configuration structure is drive specific. The SqNodeLib includes the drive specific structures and methods. Please see the drive manufacturer's documentation for details. Use `meiSqNodeInfo(.)`, to determine if the SynqNet node supports a drive interface and its type.

node	a handle to a SynqNet node object
driveIndex	an index to a drive interface on a SynqNet node. The first drive interface is 0, the second is 1, etc.
*config	a pointer to a drive specific configuration structure.

Return Values

MPIMessageOK	if <i>SqNodeDriveConfigSet</i> successfully writes the drive configuration.
---------------------	---

See Also

[meiSqNodeInfo](#) | [meiSqNodeDriveInfo](#) | [meiSqNodeConfigSet](#)

meiSqNodeDriveInfo

Declaration

```
long meiSqNodeDriveInfo(MEISqNode node,
                        long driveIndex, /* relative to the node */
                        MEISqNodeDriveInfo *info,
                        void *external); /* node specific */
```

Required Header: stdmei.h

Description

meiSqNodeDriveInfo reads a SynqNet node's drive information and writes it into a drive specific structure pointed to by *info*. The drive info structure contains read only data. SynqNet nodes may support one or more drive interfaces. The drive information can be read if the drive interface hardware supports a communication channel to the drive processor. The drive interface(s) for a SynqNet node are indexed by a number (0, 1, 2, etc.).

The drive information structure is drive specific. The SqNodeLib includes the drive specific structures and methods. Please see the drive's header file for the drive specific information structures, as well as, the drive manufacturer's documentation for details. All supported drive header files are located in the (C:\MEI)\XMP\sqNodeLib\include directory. Use `meiSqNodeInfo(.)`, to determine if the SynqNet node supports a drive interface and its type.

node	a handle to a SynqNet node object.
driveIndex	an index to a drive interface on a SynqNet node. The first drive interface is 0, the second is 1, etc.
*info	a pointer to a structure that contains general drive information.
*external	a pointer to a drive specific information structure. See the appropriate drive vendor *.h for definition. (NOTE: it can be NULL)

Return Values

MPIMessageOK	if <i>SqNodeDriveInfo</i> successfully reads the drive information.
---------------------	---

See Also

[meiSqNodeInfo](#) | [meiSqNodeConfigGet](#) | [meiSqNodeDriveConfigGet](#)

meiSqNodeDriveMapParamCount

Declaration

```
long meiSqNodeDriveMapParamCount ( MEISqNode    sqNode ,
                                   MEIDriveMap  driveMap ,
                                   long          driveIndex ,
                                   long          *paramsCount ) ;
```

Required Header: stdmei.h

Description

meiSqNodeDriveMapParamCount scans the drive map file for a drive entry that matches this node on the network. If an entry is found, then this function returns the number of drive parameters that need to be preserved for the configuration of the drive.

This function is normally used with the `meiSqNodeDriveMapParamList` function. First, this function is called in order to get the size of the drive parameter list. Then the user can use this size to allocate enough memory to hold the complete parameter list before calling `meiSqNodeDriveMapParamList` to fill in the list.

sqNode	a handle to a SynqNet node object.
driveMap	a handle to a DriveMap object.
driveIndex	an index to the drive (0, 1, 2, etc), relative to the node.
*paramsCount	pointer to the variable that will be set by this function.

Return Values

MPIMessageOK	if <i>meiSqNodeDriveMapParamCount</i> successfully scans the drive map file for a drive entry that matches this node on the network and returns the number of drive parameters that need to be preserved for the configuration of the drive.
---------------------	--

See Also

[meiSqNodeDriveMapParamList](#)

meiSqNodeDriveMapParamList

Declaration

```
long meiSqNodeDriveMapParamList ( MEISqNode          sqNode ,
                                  MEIDriveMap       driveMap ,
                                  long                driveIndex ,
                                  long                paramsCount ,
                                  MEIDriveParamInfo *driveParamInfo ) ;
```

Required Header: stdmei.h

Description

meiSqNodeDriveMapParamList scans the drive map file for an entry that matches the node on the network. If a drive entry is found, this function writes the drive parameter information about each of the drive parameters to the ***driveParamInfo*** list.

This function is normally used with the meiSqNodeDriveMapParamCount function. The meiSqNodeDriveMapParamCount function is called first to get the size of the parameter list, the user can then use this size to allocate enough memory to hold the complete parameter list before calling this function to fill in the parameter list.

sqNode	a handle to a SynqNet node object.
driveMap	a handle to a DriveMap object.
driveIndex	an index to the drive (0, 1, 2, etc), relative to the node.
paramsCount	the number of drive parameter information records that can be written to the <i>driveParamInfo</i> list.
*driveParamInfo	pointer to the list of drive parameter information records that will be filled in by this function.

Return Values

MPIMessageOK	if <i>meiSqNodeDriveMapParamList</i> successfully scans the drive map file for an entry that matches the node on the network and writes the information about each of the drive parameters to the <i>driveParamInfo</i> list.
---------------------	---

See Also

[meiSqNodeDriveMapParamCount](#)

meiSqNodeDriveMapConfigCount

Declaration

```
long meiSqNodeDriveMapConfigCount ( MEISqNode    sqNode ,
                                     MEIDriveMap  driveMap ,
                                     long          driveIndex ,
                                     long          *configCount ) ;
```

Required Header: stdmei.h

Description

meiSqNodeDriveMapConfigCount scans the drive map file for a drive entry that matches this node on the network. If an entry is found, this function returns the number of drive parameters that need to be preserved for the configuration of the drive.

This function is normally used with the `meiSqNodeDriveMapConfigList` function. This function is first called to get the size of the drive configuration list. Then the user can use this size to allocate enough memory to hold the complete configuration list before calling `meiSqNodeDriveMapConfigList` to fill in the list.

sqNode	a handle to a SynqNet node object.
driveMap	a handle to a DriveMap object.
driveIndex	an index to the drive (0, 1, 2, etc), relative to the node.
*configCount	pointer to the variable that will be set by this function.

Return Values

MPIMessageOK	if <i>meiSqNodeDriveMapConfigCount</i> successfully scans the drive map file for a drive entry that matches this node on the network and returns the number of drive parameters that need to be preserved for the configuration of the drive.
---------------------	---

See Also

[meiSqNodeDriveMapConfigList](#)

meiSqNodeDriveMapConfigList

Declaration

```
long meiSqNodeDriveMapConfigList ( MEISqNode    sqNode ,
                                   MEIDriveMap  driveMap ,
                                   long          driveIndex ,
                                   long          configCount ,
                                   long          *configList ) ;
```

Required Header: stdmei.h

Description

meiSqNodeDriveMapConfigList scans the drive map file for a drive entry that matches this node on the network. If an entry is found, this function returns the list of drive parameters that need to be preserved for the configuration of the drive.

This function is normally used with the `meiSqNodeDriveMapConfigCount` function. The `meiSqNodeDriveMapConfigCount` function is first called to get the size of the drive configuration list. Then the user can use this size to allocate enough memory to hold the complete configuration list before calling this function to fill in the list.

sqNode	a handle to a SynqNet node object.
driveMap	a handle to a DriveMap object.
driveIndex	an index to the drive (0, 1, 2, etc), relative to the node.
configCount	the number of drive parameter information records that can be written to the <i>configList</i> list.
*configList	pointer to the list of drive parameters that make up the drive configuration that will be filled in by this function.

Return Values

MPIMessageOK	if <i>meiSqNodeDriveMapConfigList</i> successfully scans the drive map file for a drive entry that matches this node on the network and returns the list of drive parameters that need to be preserved for the configuration of the drive.
---------------------	--

See Also

[meiSqNodeDriveMapConfigCount](#)

meiSqNodeDriveMapParamFileGet

Declaration

```
long meiSqNodeDriveMapParamFileGet ( MEISqNode      sqNode ,
                                     MEIDriveMap   driveMap ,
                                     long             driveIndex ,
                                     char             *driveConfigFilename ,
                                     long             append ) ;
```

Required Header: stdmei.h

Description

meiSqNodeDriveMapParamFileGet saves the current set of drive parameters in the drive to the *driveConfigFilename*.

sqNode	a handle to the SynqNet node object.
driveMap	a handle to the DriveMap object.
driveIndex	an index to the drive (0, 1, 2, etc), relative to the node.
*driveConfigFilename	the name of the file that holds the stored drive configuration file.
append	1 = The new data is appended to the existing drive configuration file if it exists. 0 = A new drive configuration file is created to hold the drive parameters. If a file already exists, it will be overwritten.

Return Values

MPIMessageOK

if *SqNodeDriveMapParamFileGet* successfully saves the current set of drive parameters in the drive to the *driveConfigFilename*.

See Also

[meiSqNodeDriveMapParamFileSet](#)

meiSqNodeDriveMapParamFileSet

Declaration

```
long meiSqNodeDriveMapParamFileSet ( MEISqNode          sqNode ,
                                     MEIDriveMap       driveMap ,
                                     long                driveIndex ,
                                     char                *driveConfigFilename ,
                                     MEISqNodeDriveParamCallback callback ,
                                     long                warning ) ;
```

Required Header: stdmei.h

Description

meiSqNodeDriveMapParamFileSet loads the drive parameters stored in the file named *driveConfigFilename* into the drive.

sqNode	a handle to the SynqNet node object.
driveMap	a handle to the DriveMap object.
driveIndex	an index to the drive (0, 1, 2, etc), relative to the node.
*driveConfigFilename	the name of the file that holds the stored drive configuration file.
callback	A callback function that this function calls to indicate if the function is changing the value of a drive parameter or setting a new drive parameter that has failed. Passing NULL for this parameter will disable the callback feature.
warning	0 = if setting a drive parameter fails, this function will fail immediately. 1 = if setting a drive parameter fails, then the function will continue with the remaining drive parameters and generate a warning by calling the callback function.

Return Values

MPIMessageOK

if *SqNodeDriveMapParamFileSet* successfully loads the drive parameters stored in the file named *driveConfigFilename* into the drive.

See Also

[meiSqNodeDriveMapParamFileGet](#)

meiSqNodeDriveMonitor

Declaration

```
long meiSqNodeDriveMonitor(MEISqNode      node,
                           long          driveIndex, /* relative to
                                                    the node */
                           MEISqNodeMonitorValue *value);
```

Required Header: stdmei.h

Description

meiSqNodeDriveMonitor reads the monitor fields from the drive and writes them into the structure pointed to by **value**.

node	a handle to a SynqNet node object.
driveIndex	an index to the drive (0, 1, 2, etc), relative to the node.
*value	pointer to a structure of monitor values

Return Values

MPIMessageOK	if <i>SqNodeDriveMonitor</i> successfully reads the monitor information.
---------------------	--

See Also

[MEISqNodeMonitorValue](#)

meiSqNodeDriveMonitorConfigGet

Declaration

```
long meiSqNodeDriveMonitorConfigGet( MEISqNode    node,
                                     long          driveIndex, /* relative to
                                                                the node */
                                     MEISqNodeDriveMonitorConfig *config);
```

Required Header: stdmei.h

Description

meiSqNodeDriveMonitorConfigGet reads a SynqNet node's drive monitor configuration and writes it into a structure pointed to by **config**. SynqNet nodes may support one or more drive interfaces. The drive monitor configuration can be read if the drive interface hardware supports a communication channel to the drive processor. The drive interface(s) for a SynqNet node are indexed by a number (0, 1, 2, etc.).

The SynqNet network packets have some extra fields that can be configured to read drive data every sample. Each monitor field is 32 bits. SynqNet nodes with drive interfaces that support drive monitoring can be configured to transmit the data. The drive manufacturer determines what data is available for monitoring. The monitor data can be specified by a predetermined index or memory address. Please see the drive's header file for the drive specific configuration structures, as well as, the drive manufacturer's documentation for details. All supported drive header files are located in the (C:\MEI)\XMP\sqNodeLib\include directory.

node	a handle to a SynqNet node object.
driveIndex	an index to a drive interface on a SynqNet node. The first drive interface is 0, the second is 1, etc.
*config	a pointer to a drive monitor configuration structure.

Return Values

MPIMessageOK

if *SqNodeDriveMonitorConfigGet* successfully reads the drive monitor configuration.

See Also

[meiSqNodeInfo](#) | [meiSqNodeDriveInfo](#)

meiSqNodeDriveMonitorConfigSet

Declaration

```
long meiSqNodeDriveMonitorConfigSet(MEISqNode node,
                                     long driveIndex, /* relative to
                                                         the node */
                                     MEISqNodeDriveMonitorConfig *config);
```

Required Header: stdmei.h

Description

meiSqNodeDriveMonitorConfigSet writes a SynqNet node's drive monitor configuration from a structure pointed to by *config*. SynqNet nodes may support one or more drive interfaces. The drive monitor configuration can be written if the drive interface hardware supports a communication channel to the drive processor. The drive interface(s) for a SynqNet node are indexed by a number (0, 1, 2, etc.).

The SynqNet network packets have some extra fields that can be configured to read drive data every sample. Each monitor field is 32 bits. SynqNet nodes with drive interfaces that support drive monitoring can be configured to transmit the data. The drive manufacturer determines what data is available for monitoring. The monitor data can be specified by a predetermined index or memory address. Please see the drive's header file for the drive specific configuration structures, as well as, the drive manufacturer's documentation for details. All supported drive header files are located in the (C:\MEI)\XMP\sqNodeLib\include directory.

node	a handle to a SynqNet node object.
driveIndex	an index to a drive interface on a SynqNet node. The first drive interface is 0, the second is 1, etc.
*config	a pointer to a drive monitor configuration structure.

Return Values

MPIMessageOK	if <i>SqNodeDriveMonitorConfigSet</i> successfully writes the drive monitor configuration.
---------------------	--

See Also

[meiSqNodeInfo](#) | [meiSqNodeDriveInfo](#)

meiSqNodeDriveParamCalculate

Declaration

```
long meiSqNodeDriveParamCalculate(MEISqNode    sqNode ,
                                  long          driveIndex) ;
```

Required Header: stdmei.h

Description

Some drives need to calculate some internal quantities after a drive parameter has been changed. The **meiSqNodeDriveParamCalculate** function will instruct the drive to calculate its internal quantities. This feature is not supported or required by all drives.

sqNode	a handle to a SynqNet node object
driveIndex	an index to the drive (0, 1, 2, etc), relative to the node.

Return Values

MPIMessageOK	if <i>SqNodeDriveParamCalculate</i> successfully has the drive to calculate its internal quantities.
---------------------	--

See Also

meiSqNodeDriveParamClear

Declaration

```
long meiSqNodeDriveParamClear(MEISqNode    sqNode ,
                               long          driveIndex) ;
```

Required Header: stdmei.h

Description

meiSqNodeDriveParamClear clears the previously saved drive by loading the default set of drive parameters into the current and non-volatile storage on the drive. These drive parameters will be used each time this drive is subsequently started (after a power-on or network reset). The default drive parameters will take effect immediately.

NOTE: This function may not be supported by all drives. The default set of drive parameters may be different between different drive types and different drive manufactures.

sqNode	a handle to a SynqNet node object
driveIndex	an index to the drive (0, 1, 2, etc), relative to the node.

Return Values

MPIMessageOK	if <i>SqNodeDriveParamClear</i> successfully clears the previously saved drive by loading the default set of drive parameters into the current and non-volatile storage on the drive.
---------------------	---

See Also

[meiSqNodeDriveParamReload](#)

meiSqNodeDriveParamGet

Declaration

```
long meiSqNodeDriveParamGet ( MEISqNode          node ,
                              long                driveIndex ,
                              long                param ,
                              MEIDriveMapParamType paramType ,
                              MEIDriveMapParamValue *value ) ;
```

Required Header: stdmei.h

Description

meiSqNodeDriveParamGet reads a drive parameter from the drive and fills in the appropriate field of the union pointed to by *value*. The *paramType* defines the type of data that is read from the drive and also defines which field will be used in the *value* union.

node	a handle to the SynqNet node object.
driveIndex	an index to the drive (0, 1, 2, etc), relative to the node.
param	an index for the drive parameter that is being accessed.
paramType	the type of the data read from the drive and which field will be used in the <i>value</i> union.
*value	a pointer to the union that will be filled in.

Return Values

MPIMessageOK	if <i>SqNodeDriveParamGet</i> successfully reads a drive parameter from the drive and fills in the appropriate field of the union pointed to by <i>value</i> .
---------------------	--

See Also

[meiSqNodeDriveParamSet](#)

meiSqNodeDriveParamListGet

Declaration

```
long meiSqNodeDriveParamListGet ( MEISqNode node ,
                                  long driveIndex ,
                                  long size ,
                                  long *paramList ,
                                  MEIDriveMapParamType *paramTypes ,
                                  MEIDriveMapParamValue *paramValues ) ;
```

Required Header: stdmei.h

Description

meiSqNodeDriveParamListGet reads a series of drive parameters from the drive and fills in the appropriate fields of the unions pointed to by *paramValues*. The *paramTypes* defines the type of data that is read from the drive and also defines which fields in the *paramValues* unions are going to be used.

node	a handle to the SynqNet node object.
driveIndex	an index to the drive (0, 1, 2, etc), relative to the node.
size	the number of drive parameters to be read.
*paramList	a pointer to a list of the drive parameter indexes that are being accessed.
*paramTypes	a pointer to a list of drive parameter types to be read from the drive and which field in the paramValues union is going to be used.
*paramValues	a pointer to a list of unions that will be filled in by this function.

Return Values

MPIMessageOK

if *SqNodeDriveParamListGet* successfully reads a series of drive parameters from the drive and fills in the appropriate fields of the unions pointed to by *paramValues*.

See Also

[meiSqNodeDriveParamListSet](#)

meiSqNodeDriveParamListSet

Declaration

```
long meiSqNodeDriveParamListSet ( MEISqNode node ,
                                  long driveIndex ,
                                  long size ,
                                  long *paramList ,
                                  MEIDriveMapParamType *paramTypes ,
                                  MEIDriveMapParamValue *paramValues ) ;
```

Required Header: stdmei.h

Description

meiSqNodeDriveParamListSet writes a series of drive parameters pointed to by **value** to the drive. The **paramTypes** defines each type of data item that is written to the drive and also defines which field in the **paramValues** unions are going to be used.

node	a handle to the SynqNet node object.
driveIndex	an index to the drive (0, 1, 2, etc), relative to the node.
size	the number of drive parameters to be written.
*paramList	a pointer to a list of drive parameter types to be written to the drive and which field in the paramValues union is going to be used.
*paramTypes	a pointer to a list of the drive parameter indexes that are being accessed.
*paramValues	a pointer to a list of unions that will be written to the drive.

Return Values

MPIMessageOK	if <i>SqNodeDriveParamListSet</i> successfully writes a series of drive parameters pointed to by value to the drive.
---------------------	---

See Also

[meiSqNodeDriveParamListGet](#)

meiSqNodeDriveParamReload

Declaration

```
long meiSqNodeDriveParamReload(MEISqNode    sqNode ,
                                long          driveIndex) ;
```

Required Header: stdmei.h

Description

meiSqNodeDriveParamReload overwrites the current set of drive parameters with the set from the non-volatile storage on the drive. These new drive parameters will take effect immediately.

sqNode	a handle to a SynqNet node object
driveIndex	an index to the drive (0, 1, 2, etc), relative to the node.

Return Values

MPIMessageOK	if <i>SqNodeDriveParamReload</i> successfully overwrites the current set of drive parameters with the set from the non-volatile storage on the drive.
---------------------	---

See Also

[meiSqNodeDriveParamClear](#)

meiSqNodeDriveParamRestore

Declaration

```
long meiSqNodeDriveParamRestore(MEISqNode    sqNode ,
                                long           driveIndex) ;
```

Required Header: stdmei.h

Description

meiSqNodeDriveParamRestore loads the default set of drive parameters into current set of drive parameters on the drive. The default drive parameters will take effect immediately.

sqNode	a handle to a SynqNet node object
driveIndex	an index to the drive (0, 1, 2, etc), relative to the node.

Return Values

MPIMessageOK	if <i>SqNodeDriveParamRestore</i> successfully loads the default set of drive parameters into current set of drive parameters on the drive.
---------------------	---

See Also

[meiSqNodeDriveParamStore](#)

meiSqNodeDriveParamSet

Declaration

```
long meiSqNodeDriveParamSet(MEISqNode node,
                             long driveIndex,
                             long param,
                             MEIDriveMapParamType paramType,
                             MEIDriveMapParamValue *value);
```

Required Header: stdmei.h

Description

meiSqNodeDriveParamSet writes the drive parameter that is pointed to by *value* to the drive. The *paramType* defines the type of data that is written to the drive and also defines which field will be used in the *value* union.

node	a handle to the SynqNet node object.
driveIndex	an index to the drive (0, 1, 2, etc), relative to the node.
param	an index for the drive parameter that is being accessed.
paramType	the type of data being written to the drive and which field will be used in the <i>value</i> union.
*value	pointer to the union that will be written to the drive.

Return Values

MPIMessageOK	if <i>SqNodeDriveParamSet</i> successfully writes the drive parameter that is pointed to by <i>value</i> to the drive.
---------------------	--

See Also

[meiSqNodeDriveParamGet](#)

meiSqNodeDriveParamStore

Declaration

```
long meiSqNodeDriveParamStore(MEISqNode    sqNode ,
                               long          driveIndex) ;
```

Required Header: stdmei.h

Description

meiSqNodeDriveParamStore saves the drive parameters into non-volatile storage on the drive. These drive parameters will be used each time the drive is subsequently started (after a power-on or network reset).

NOTE: This function may not be supported by all drives.

sqNode	a handle to a SynqNet node object
driveIndex	an index to the drive (0, 1, 2, etc), relative to the node.

Return Values

MPIMessageOK	if <i>SqNodeDriveParamStore</i> successfully saves the drive parameters into non-volatile storage on the drive.
---------------------	---

See Also

[meiSqNodeDriveParamRestore](#)

meiSqNodeAnalogIn

Declaration

```
long meiSqNodeAnalogIn(MEISqNode node,
                       long channel,
                       long *state);
```

Required Header: stdmei.h

Change History: Added in the 03.02.00

Description

meiSqNodeAnalogIn gets the current state of an analog input on a SynqNet node.

node	a handle to a SynqNet node object.
channel	the index of the analog input channel (with respect to the node).
*state	a pointer to where the current state of the input is written by this function.

Return Values

MPIMessageOK

if *SqNodeAnalogIn* successfully gets the current state of an analog input on a SynqNet node.

See Also

meiSqNodeAnalogOutGet

Declaration

```
long meiSqNodeAnalogOutGet(MEISqNode node,
                           long channel,
                           long *state);
```

Required Header: stdmei.h

Change History: Added in the 03.02.00

Description

meiSqNodeAnalogOutGet reads the current state of an analog output on a SynqNet node.

node	a handle to a SynqNet node object.
channel	the index of the analog output channel (with respect to the node).
*state	a pointer to where the current state of the output is written by this function.

Return Values

MPIMessageOK

if *SqNodeAnalogOutGet* successfully reads the current state of an analog output on a SynqNet node.

See Also

[meiSqNodeAnalogSet](#)

meiSqNodeAnalogOutSet

Declaration

```
long meiSqNodeAnalogOutSet(MEISqNode    node ,
                           long          channel ,
                           long          state ,
                           long          wait );
```

Required Header: stdmei.h

Change History: Added in the 03.02.00

Description

meiSqNodeAnalogOutSet changes the current state of an analog output on a SynqNet node.

node	a handle to a SynqNet node object.
channel	the index of the analog output channel (with respect to the node).
state	the desired state of the analogue output.
wait	determines what happens if two output functions are called in short succession. See Overview of Motor I/O: Output Waits .

Return Values

MPIMessageOK

if *SqNodeAnalogOutSet* successfully changes the current state of an analog output on a SynqNet node.

See Also

[meiSqNodeAnalogOutGet](#)

meiSqNodeDigitalIn

Declaration

```
long meiSqNodeDigitalIn(MEISqNode node,
                        long bitStart,
                        long bitCount,
                        unsigned long *state );
```

Required Header: stdmei.h

Change History: Added in the 03.02.00

Description

meiSqNodeDigitalIn gets the current state of multiple digital inputs on the specified SynqNet node.

node	a handle to a SynqNet node object.
bitStart	the first bit.
bitCount	the number of bits to be read.
*state	a pointer to where the current state of the input bits is written to by this function.

Return Values

MPIMessageOK

if *SqNodeDigitalIn* successfully gets the current state of multiple digital inputs on the specified SynqNet node.

See Also

meiSqNodeDigitalOutGet

Declaration

```
long meiSqNodeDigitalOutGet(MEISqNode node,
                             long bitStart,
                             long bitCount,
                             unsigned long *state);
```

Required Header: stdmei.h

Change History: Added in the 03.02.00

Description

meiSqNodeDigitalOutGet reads the current state of the multiple digital output bits on the specified SynqNet node.

node	a handle to a SynqNet node object.
bitStart	the first bit.
bitCount	the number of bits to be read.
*state	a pointer to where the current state of the output bits is written to by this function.

Return Values

MPIMessageOK

if *SqNodeAnalogOutGet* successfully reads the current state of the multiple digital output bits on the specified SynqNet node.

See Also

[meiSqNodeDigitalOutSet](#)

meiSqNodeDigitalOutSet

Declaration

```
long meiSqNodeDigitalOutSet(MEISqNode    node,
                             long          bitStart,
                             long          bitCount,
                             unsigned long state,
                             long          wait);
```

Required Header: stdmei.h

Change History: Added in the 03.02.00

Description

meiSqNodeDigitalOutSet changes the state of multiple digital outputs on the specified SynqNet node.

node	a handle to a SynqNet node object.
bitStart	the first bit.
bitCount	the number of bits to be changed.
state	a pointer to where the current state of the output bits is written to by this function.
wait	Boolean flag indicating if the new output state is applied immediately or if a wait is inserted so that any previous output set is transmitted over SynqNet and applied to the output before this function. You should be able to use TRUE for this argument in most applications.

Return Values

MPIMessageOK	if <i>SqNodeAnalogOutSet</i> successfully changes the state of multiple digital outputs on the specified SynqNet node.
---------------------	--

See Also

[meiSqNodeDigitalOutGet](#)

meiSqNodeSegmentAnalogIn

Declaration

```
long meiSqNodeSegmentAnalogIn(MEISqNode node,
                               long segment,
                               long channel,
                               long *state);
```

Required Header: stdmei.h

Change History: Added in the 03.02.00

Description

meiSqNodeSegmentAnalogIn gets the current state of an analog input on the specified slice on a SynqNet node.

node	a handle to a SynqNet node object.
segment	the index of the slice/module attached to this SynqNet node.
channel	the index of the analog input channel (with respect to the slice).
*state	a pointer to where the current state of the input is written by this function.

Return Values

MPIMessageOK

if *SqNodeSegmentAnalogIn* successfully gets the current state of an analog input on the specified slice on a SynqNet node.

See Also

meiSqNodeSegmentAnalogOutGet

Declaration

```
long meiSqNodeSegmentAnalogOutGet ( MEISqNode    node ,
                                     long           segment ,
                                     long           channel ,
                                     long           *state ) ;
```

Required Header: stdmei.h

Change History: Added in the 03.02.00

Description

meiSqNodeSegmentAnalogOutGet gets the current state of an analog output on the specified slice on a SynqNet node.

node	a handle to a SynqNet node object.
segment	the index of the slice/module attached to this SynqNet node.
channel	the index of the analog output channel (with respect to the slice).
*state	a pointer to where the current state of the output is written by this function.

Return Values

MPIMessageOK

if *SqNodeSegmentAnalogOutGet* successfully gets the current state of an analog output on the specified slice on a SynqNet node.

See Also

[meiSqNodeSegmentAnalogOutSet](#)

meiSqNodeSegmentAnalogOutSet

Declaration

```
long meiSqNodeSegmentAnalogOutSet ( MEISqNode    node ,
                                     long           segment ,
                                     long           channel ,
                                     long           state ,
                                     long           wait ) ;
```

Required Header: stdmei.h

Change History: Added in the 03.02.00

Description

meiSqNodeSegmentAnalogOutSet changes the current state of an analog output on the specified slice on a SynqNet node.

node	a handle to a SynqNet node object.
segment	the index of the slice/module attached to this SynqNet node.
channel	the index of the analog input channel (with respect to the slice).
state	the desired state of the analog output.
wait	determines what happens if two output functions are called in short succession. See Overview of Motor I/O: Output Waits .

Return Values

MPIMessageOK	if <i>SqNodeSegmentAnalogOutSet</i> successfully changes the current state of an analog output on the specified slice on a SynqNet node.
---------------------	--

See Also

[meiSqNodeSegmentAnalogOutGet](#)

meiSqNodeSegmentInfo

Declaration

```
long meiSqNodeSegmentInfo(MEISqNode node,
                           long segment,
                           MEISqNodeSegmentInfo *info);
```

Required Header: stdmei.h

Change History: Added in the 03.02.00

Description

meiSqNodeSegmentInfo reads the constant data about a segment on a SynqNet node and fills in the structure pointer by the *info* argument.

node	a handle to a SynqNet node object
segment	the index of the slice / module attached to this SynqNet node.
*info	a pointer to a structure that will be filled in by this function.

Return Values

MPIMessageOK

if *SqNodeSegmentInfo* successfully reads the constant data about a segment on a SynqNet node and fills in the structure pointer by the *info* argument.

See Also

[MEISqNodeSegmentInfo](#)

meiSqNodeSegmentDigitalIn

Declaration

```
long meiSqNodeSegmentDigitalIn(MEISqNode    node ,
                                long          segment ,
                                long          bitStart ,
                                long          bitCount ,
                                unsigned long *state);
```

Required Header: stdmei.h

Change History: Added in the 03.02.00

Description

meiSqNodeSegmentDigitalIn gets the current state of multiple digital inputs on the specified slice on a SynqNet node.

node	a handle to a SynqNet node object.
segment	the index of the slice/module attached to this SynqNet node.
bitStart	the first bit
bitCount	the number of bits to be read.
*state	a pointer to a long word that will be filled in by this function.

Return Values

MPIMessageOK

if *SqNodeSegmentDigitalIn* successfully gets the current state of multiple digital inputs on the specified slice on a SynqNet node.

See Also

meiSqNodeSegmentDigitalOutGet

Declaration

```
long meiSqNodeSegmentDigitalOutGet(MEISqNode    node ,
                                   long          segment ,
                                   long          bitStart ,
                                   long          bitCount ,
                                   unsigned long *state);
```

Required Header: stdmei.h

Change History: Added in the 03.02.00

Description

meiSqNodeSegmentDigitalOutGet changes the state of multiple digital outputs on the specified slice on a SynqNet node.

node	a handle to a SynqNet node object.
segment	the index of the slice/module attached to this SynqNet node.
bitStart	the first bit
bitCount	the number of bits to be read.
state	a pointer to where the current state of the output bits is written to by this function.

Return Values

MPIMessageOK

if *SqNodeSegmentDigitalOutGet* successfully changes the state of multiple digital outputs on the specified slice on a SynqNet node.

See Also

[meiSqNodeSegmentDigitalOutSet](#)

meiSqNodeSegmentDigitalOutSet

Declaration

```
long meiSqNodeSegmentDigitalOutSet(MEISqNode    node,
                                   long           segment,
                                   long           bitStart,
                                   long           bitCount,
                                   unsigned long state,
                                   long           wait);
```

Required Header: stdmei.h

Change History: Added in the 03.02.00

Description

meiSqNodeSegmentDigitalOutSet sets the current state of the multiple digital output bits on the specified slice/module on a SynqNet node.

node	a handle to a SynqNet node object.
segment	the index of the slice/module attached to this SynqNet node.
bitStart	the first bit
bitCount	the number of bits to be read.
state	a pointer to where the current state of the output bits is written to by this function.
wait	a Boolean flag indicating if the new output state is applied immediately or a wait is inserted so that any previous output set is transmitted over SynqNet. You should be able to use TRUE for this argument in most applications.

Return Values

MPIMessageOK	if <i>SqNodeSegmentDigitalOutSet</i> successfully gets the current state of the multiple digital output bits on the specified slice/module on a SynqNet node.
---------------------	---

See Also

[meiSqNodeSegmentDigitalOutGet](#)

meiSqNodeSegmentUserDataGet

Declaration

```
long meiSqNodeSegmentUserDataGet ( MEISqNode          node ,
                                   long                segment ,
                                   MEISqNodeSegmentUserData *data ) ;
```

Required Header: stdmei.h

Change History: Added in the 03.02.00

Description

Modules attached to a SQID node have a small section of non-volatile memory that can be used for any purpose by the user. **meiSqNodeSegmentUserDataGet** gets the user data from a segment on a SynqNet node.

node	a handle to a SynqNet node object.
segment	the index of the slice/module attached to this SynqNet node.
data	a pointer to where the user data is written by this function.

Return Values

MPIMessageOK

if *SqNodeSegmentUserDataGet* successfully gets the user data from a segment on a SynqNet node.

See Also

[meiSqNodeSegmentUserDataSet](#) | [MPI Overview I/O: User Data](#)

meiSqNodeSegmentUserDataSet

Declaration

```
long meiSqNodeSegmentUserDataSet ( MEISqNode node ,
                                   long segment ,
                                   MEISqNodeSegmentUserData *data ) ;
```

Required Header: stdmei.h

Change History: Added in the 03.02.00

Description

Modules attached to a SQID node have a small section of non-volatile memory that can be used for any purpose by the user. **meiSqNodeSegmentUserDataSet** changes the user data stored on a segment on a SynqNet node.

node	a handle to a SynqNet node object.
segment	the index of the slice/module attached to this SynqNet node.
data	a pointer to the new user data.

Return Values

MPIMessageOK

if *SqNodeSegmentUserDataSet* successfully changes the user data stored on a segment on a SynqNet node.

See Also

[meiSqNodeSegmentUserDataGet](#) | [MPI Overview I/O: User Data](#)

meiSqNodeDownload

Declaration

```
long meiSqNodeDownload(MEISqNode node,
                       MEISqNodeDownloadParams *params);
```

Required Header: stdmei.h

Description

meiSqNodeDownload SqNodeDownload reads a binary image from a file and writes it into a SynqNet node's non-volatile storage. SynqNet nodes may support one or more drive interfaces. SqNodeDownload can also write binary images to a drives' non-volatile storage if the drive interface hardware supports a communication channel to the drive processor. The drive interface(s) for a SynqNet node are indexed by a number (0, 1, 2, etc.).

The SynqNet node binary files are node specific. Please see the [Node Binary Files: Product Table](#).

The SynqNet drive binary files are drive specific. The SqNodeLib includes the drive specific code necessary to support various hardware download protocols. Please see the drive manufacturer's documentation for details. Use meiSqNodeInfo(.), to determine if the SynqNet node supports a drive interface and it's type.

The binary download process requires a significant amount of time, probably between 5 to 30 seconds, depending on the node/drive type and file size. A callback function pointer is provided in the MEISqNodeDownloadParams structure for the calling application to monitor the download progress.

node	a handle to a SynqNet node object
*params	a pointer to the download parameters structure.

Return Values

MPIMessageOK	if <i>SqNodeNumber</i> successfully reads the network number
---------------------	--

See Also

[meiSqNodeInfo](#) | [meiSynqNetInfo](#) | [MEISqNodeDownloadParams](#) | [MEISqNodeChannel](#) | [MEISqNodeCallback](#)

meiSqNodeFlashErase

Declaration

```
long meiSqNodeFlashErase(MEISqNode sqNode) ;
```

Required Header: stdmei.h

Description

meiSqNodeFlashErase brings the SynqNet network down to discovery mode, sends a service command down to the node that erases its runtime flash, and leaves the network down. The next time the network is brought up to Synq mode the node will be running off its boot image.

node	a handle to a SynqNet node object.
-------------	------------------------------------

Return Values

MPIMessageOK

if *SqNodeFlashErase* successfully brings the SynqNet network down to discovery mode, sends a service command down to the node that erases its runtime flash, and leaves the network down.

See Also

meiSqNodeFpgaFileNameVerify

Declaration

```
long meiSqNodeFpgaFileNameVerify(MEISqNode    sqNode ,
                                char*         fileName ) ;
```

Required Header: stdmei.h

Description

meiSqNodeFpgaFileNameVerify verifies that the filename provided is compatible with a given sqNode.

sqNode	a handle to an SqNode object.
fileName	a pointer to a string containing the name of an SqNode image file.

Return Values

MPIMessageOK	If the FPGA image file is compatible with the specified SqNode.
MEISqNodeMessageFILE_NODE_MISMATCH	If the FPGA image file is NOT compatible with the specified SqNode.

See Also

meiSqNodeStatusClear

Declaration

```
long meiSqNodeStatusClear(MEISqNode node) ;
```

Required Header: stdmei.h

Description

meiSqNodeStatusClear clears node CRC errors on all ports, clears node Packet errors, clears node ioAbort state, and resets SqNode events.

node	a handle to a SynqNet node object
-------------	-----------------------------------

Return Values

MPIMessageOK

if *SqNodeStatusClear* successfully clears node CRC errors on all ports, clears node Packet errors, clears node ioAbort state, and resets SqNode events.

See Also

[MEIEventTypeSQNODE](#)

meiSqNodeVerify

Declaration

```
long meiSqNodeVerify(MEISqNode node,
                    MEISqNodeDownloadParams *params );
```

Required Header: stdmei.h

Description

meiSqNodeVerify verifies that the runtime image on a sqNode matches the data contained in a provided image file.

node	a handle to SqNode object.
*params	a pointer to parameters used in the verify routine.

Return Values

MPIMessageOK	If the <i>meisqNodeVerify</i> successfully verifies that there is a matching runtime image.
MEISqNodeMessageVERIFY_FAIL	If the file provided does not match the runtime image on the node.

See Also

meiSqNodeEventNotifyGet

Declaration

```
long meiSqNodeEventNotifyGet ( MEISqNode      node ,
                               MPIEventMask *eventMask ,
                               void             *external ) ;
```

Required Header: stdmei.h

Description

meiSqNodeEventNotifyGet reads the event mask (that specifies the event types for which host notification has been requested) to the location pointed to by **eventMask**, and also writes it into the implementation specific location pointed to by **external**. (if external is not NULL).

Use the event mask macros `mpiEventMaskGET(.)`, `mpiEventMaskBitGET(.)`, etc. to decode the eventMask.

The event notification data in external is in addition to the event notification data in eventMask. If external is NULL, the event notification data will not be copied to the external pointer.

Remarks

external either points to a structure of type **MEIEventNotifyData{}** or is NULL.

node	a handle to a SynqNet node object
*eventMask	pointer to an event mask, whose bits are defined by the MPI/MEIEventType enumerations.
*external	pointer to external

Return Values

MPIMessageOK	if <i>SqNodeEventNotifyGet</i> successfully reads the event mask
MPIMessageARG_INVALID	if the eventMask pointer is NULL

See Also

[MPI/MEIEventType](#) | [MEIEventNotifyData](#) | [MEIEventStatusInfo](#)

meiSqNodeEventNotifySet

Declaration

```
long meiSqNodeEventNotifySet(MEISqNode node,
                             MPIEventMask eventMask,
                             void *external);
```

Required Header: stdmei.h

Description

meiSqNodeEventNotifySet requests host notification of the event(s) that are generated by SqNode and specified by **eventMask**, and also specified by the implementation specific location pointed to by **external** (if external is not NULL).

Use the event mask macros `meiEventMaskSQNODE(.)`, `mpiEventMaskSET(.)`, `mpiEventMaskBitSET(.)`, `mpiEventMaskCLEAR(.)`, etc. to create the eventMask.

The event notification data in external is in addition to the event notification data in eventMask. If external is NULL, the event notification data will not be copied to the external pointer.

Remarks

external either points to a structure of type **MEIEventNotifyData{}** or is NULL.

The MEIEventNotifyData{.} structure is an array of controller addresses, whose contents are placed into the MEIEventStatusInfo{.} structure (of all events generated by this object).

node	a handle to a SynqNet node object
eventMask	pointer to an event mask, whose bits are defined by the MPI/MEIEventType enumerations.
*external	pointer to external

Return Values

MPIMessageOK	if <i>SynqNetEventNotifySet</i> successfully writes the event mask
MPIMessageARG_INVALID	if the eventMask pointer is NULL

See Also

[MEI/MPIEventType](#) | [MEIEventNotifyData](#) | [MEIEventStatusInfo](#)

meiSqNodeEventReset

Declaration

```
long meiSqNodeEventReset ( MEISqNode      sqNode ,
                           MPIEventMask  eventMask ) ;
```

Required Header: stdmei.h

Description

meiSqNodeEventReset is a method used to reset events that have been latched on a node. Events that can be reset by this method include:

See [MEIEventType](#).

```
/* SqNode events */
MEIEventTypeSQNODE_IO_ABORT,
MEIEventTypeSQNODE_NODE_DISABLE,
MEIEventTypeSQNODE_NODE_ALARM,
MEIEventTypeSQNODE_ANALOG_POWER_FAULT,
MEIEventTypeSQNODE_USER_FAULT,
MEIEventTypeSQNODE_NODE_FAILURE,
```

sqNode	a handle to a SynqNet node object
eventMask	pointer to an event mask, whose bits are defined by the MPI/MEIEventType enumerations.

Return Values

MPIMessageOK	if <i>SynqNetEventReset</i> successfully writes the event mask
MPIMessageARG_INVALID	if the eventMask pointer is NULL

See Also

meiSqNodeMemory

Declaration

```
long meiSqNodeMemory(MEISqNode node,
                    void **memory) ;
```

Required Header: stdmei.h

Description

meiSqNodeMemory writes an address (that can be used to access SqNode memory) to the contents of memory. This address (or an address calculated from it) can be passed as the src argument to `mpiSqNodeMemoryGet(.)` or the dst argument to `mpiSqNodeMemorySet(.)`.

node	a handle to a SynqNet node object
**memory	a pointer to an SqNode memory address.

Return Values

MPIMessageOK	if <i>SqNodeMemory</i> successfully writes the SqNode memory address to the contents of memory.
---------------------	---

See Also

[meiSqNodeMemoryGet](#) | [meiSqNodeMemorySet](#)

meiSqNodeMemoryGet

Declaration

```
long meiSqNodeMemoryGet ( MEISqNode    node ,
                          void           *dst ,
                          void           *src ,
                          long          count ) ;
```

Required Header: stdmei.h

Description

meiSqNodeMemoryGet reads **count** bytes of an SqNode's memory, starting from address **src** and writes it to application memory, starting at address **dst**.

node	a handle to a SynqNet node object
*dst	pointer to the destination address in application memory
*src	pointer to the source address in SqNode memory
count	number of bytes to copy

Return Values

MPIMessageOK	if <i>SqNodeMemoryGet</i> successfully copies data from SqNode memory to application memory.
---------------------	--

See Also

[meiSqNodeMemory](#) | [meiSqNodeMemorySet](#)

meiSqNodeMemorySet

Declaration

```
long meiSqNodeMemorySet ( MEISqNode    node ,
                          void            *dst ,
                          void            *src ,
                          long            count ) ;
```

Required Header: stdmei.h

Description

meiSqNodeMemorySet reads count bytes of application memory, starting from address **src** and writes it to an SqNode's memory, starting at address **dst**.

node	a handle to a SynqNet node object
*dst	pointer to the destination address in SqNode memory
*src	pointer to the source address in application memory
count	number of bytes to copy

Return Values

MPIMessageOK	if <i>SqNodeMemorySet</i> successfully copies data from application memory to SqNode memory.
---------------------	--

See Also

[meiSqNodeMemory](#) | [meiSqNodeMemoryGet](#)

meiSynqNetControl

Declaration

```
MPIControl meiSqNodeControl(MEISqNode node);
```

Required Header: stdmei.h

Description

meiSqNodeControl returns a handle to the control object associated with the SqNode object.

node	a handle to a SynqNet node object
-------------	-----------------------------------

Return Values

MPIControl	a handle to a control object
-------------------	------------------------------

MPIHandleVOID	if node is not valid
----------------------	----------------------

See Also

[meiSqNodeCreate](#) | [mpiControlCreate](#)

meiSqNodeNumber

Declaration

```
long meiSqNodeNumber( MEISqNode    node ,
                      long          *number ) ;
```

Required Header: stdmei.h

Description

meiSqNodeNumber reads the index of a SynqNet **node** and writes it into the contents of a long pointed to by **number**. Each SqNode associated with a controller is indexed by a identification number (0, 1, 2, etc.).

node	a handle to a SynqNet node object
*number	a pointer to the index of a SynqNet node.

Return Values

MPIMessageOK	if <i>SqNodeNumber</i> successfully reads the network number.
---------------------	---

See Also

[meiSynqNetInfo](#) | [meiSynqNetNumber](#)

MEISqNodeCallback

Definition

```
typedef long (*MEISqNodeCallback)(long percentage);
```

Description

MEISqNodeCallback is a pointer to a function, which can be used to monitor the `meiSqNodeDownload(...)` progress.

percentage

The portion (from 0% to 100%) of memory download that has been completed.

See Also

[meiSqNodeDownload](#)

MEISqNodeChannel

Definition

```
typedef enum MEISqNodeChannel {
    MEISqNodeChannelDRIVE0 ,
    MEISqNodeChannelDRIVE1 ,
    MEISqNodeChannelDRIVE2 ,
    MEISqNodeChannelDRIVE3 ,
    MEISqNodeChannelDRIVE4 ,
    MEISqNodeChannelDRIVE5 ,
    MEISqNodeChannelDRIVE6 ,
    MEISqNodeChannelDRIVE7 ,
    MEISqNodeChannelNODE ,
} MEISqNodeChannel ;
```

Description

MEISqNodeChannel is an enumeration of communication interfaces to a node. All SynqNet nodes support a single NODE channel to the network interface device. SynqNet nodes may support one or more drive channels to a drive processor. DRIVE channels are indexed by an enumeration (DRIVE0, DRIVE1, DRIVE2, etc.).

MEISqNodeChannelDRIVE0	interface to drive number 0
MEISqNodeChannelDRIVE1	interface to drive number 1
MEISqNodeChannelDRIVE2	interface to drive number 2
MEISqNodeChannelDRIVE3	interface to drive number 3
MEISqNodeChannelDRIVE4	interface to drive number 4
MEISqNodeChannelDRIVE5	interface to drive number 5
MEISqNodeChannelDRIVE6	interface to drive number 6
MEISqNodeChannelDRIVE7	interface to drive number 7
MEISqNodeChannelNODE	interface to the node device

See Also

[meiSqNodeCommand](#) | [meiSqNodeDownload](#)

MEISqNodeCmdHeader

Definition

```
typedef struct MEISqNodeCmdHeader {
    MEISqNodeChannel    channel;    /* internal node destination */
    MEISqNodeMemory    memory;
    MEISqNodeDataSize  size;
    MEISqNodeCmdType   type;      /* read/write command */
} MEISqNodeCmdHeader;
```

Description

MEISqNodeCmdHeader specifies the service command communication interface to the device, the memory region on the device to access, the data size, and type.

channel	Communication interface to a device. See MEISqNodeChannel .
memory	The memory region to access. See MEISqNodeMemory .
size	The length of data to send or receive. See MEISqNodeDataSize .
type	The service command action (read or write). See MEISqNodeCmdType .

See Also

[meiSqNodeCommand](#) | [MEISqNodeCommand](#)

MEISqNodeCmdType

Definition

```
typedef enum MEISqNodeCmdType {  
    MEISqNodeCmdTypeREAD,  
    MEISqNodeCmdTypeWRITE,  
} MEISqNodeCmdType;
```

Description

MEISqNodeCmdType is an enumeration of service command types to send to a node or drive.

MEISqNodeCmdTypeREAD	read data
MEISqNodeCmdTypeWRITE	write data

See Also

[meiSqNodeCommand](#) | [MEISqNodeCmdHeader](#)

MEISqNodeCommand

Definition

```
typedef struct MEISqNodeCommand {  
    MEISqNodeCmdHeader header;  
    unsigned long address; /* command registers */  
    unsigned long data; /* command data */  
} MEISqNodeCommand;
```

Description

MEISqNodeCommand specifies the service command. It includes a header structure (channel, memory, size, and type), a destination address, and the data.

header	A structure that specifies the channel, memory region, and data size. See MEISqNodeCmdHeader .
address	A memory location to read or write the data.
data	The command data to send.

See Also

[meiSqNodeCommand](#) | [MEISqNodeResponse](#)

MEISqNodeConfig

Definition

```
typedef struct MEISqNodeConfig {
    MEISqNodeConfigAlarm           nodeAlarm;
    MEISqNodeConfigIoAbort        ioAbort;
    MEISqNodeConfigPacketError    upStreamError;
    MEISqNodeConfigPacketError    downStreamError;
    MEISqNodeConfigUserFault      userFault;
    MEISqNodeFeedbackSecondary    feedbackSecondary
                                   [ MEISqNodeMaxFEEDBACK\_SECONDARY ];
} MEISqNodeConfig;
```

Description

MEISqNodeConfig specifies the SynqNet node configurations.

nodeAlarm	A structure to configure a SynqNet node's trigger conditions for the Node Alarm output bit. The node alarm circuit is node specific, but is intended to notify users when the node has a problem. The nodeAlarm occurs on an ioAbort, DedicatedInAMP_FAULT (one per motor/drive) or an FPGA fails to operate with run-time code. See MEISqNodeConfigIoAbort and MEISqNodeConfigNodeAlarm for the trigger configurations.
ioAbort	A structure to configure a SynqNet node's trigger conditions for an I/O Abort action. When an ioAbort is triggered, the SynqNet node's outputs are disabled (set to the power-on condition). See MEISqNodeConfigIoAbort for the trigger configurations.
upStreamError	A structure used to configure the fault and failure limits for the upstream SynqNet packets. The controller keeps track of how many bad packets are received from the Node and performs the appropriate actions when the fault and fail limits are reached. See MEISqNodeConfigPacketError for appropriate ranges and resulting actions. NOTE: Saving the upStreamError values to non-volatile flash memory is currently not supported. These values need to be set after each controller reset or power on.

downStreamError	A structure used to configure the fault and failure limits for the downstream SynqNet packets. The node keeps track of how many bad packets are received from the controller and performs the appropriate actions when the fault and fail limits are reached. See MEISqNodeConfigPacketError for appropriate ranges and resulting actions.
userFault	A structure to configure the trigger conditions for a SynqNet node user fault. When a user fault is triggered, a node ioAbort and/or an action on each motor will occur. See MEISqNodeConfigUserFault for the trigger configurations.
feedbackSecondary	A structure to configure the secondary encoder resources on the node. See MEISqNodeFeedbackSecondary for more information.

See Also

[meiSqNodeConfigGet](#) | [meiSqNodeConfigSet](#) | [MEISqNodeConfigPacketError](#)

MEISqNodeConfigIoAbort

Definition

```
typedef struct MEISqNodeConfigIoAbort {
    MEISqNodeConfigTrigger    synqLost;        /* communication error */
    MEISqNodeConfigTrigger    nodeDisable;     /* external input */
    MEISqNodeConfigTrigger    powerFault;      /* analog power failure */
    long                      userFault;      /* TRUE = user fault causes ioabort */
} MEISqNodeConfigIoAbort;
```

Description

MEISqNodeConfigIoAbort specifies the SynqNet node configurations to generate an I/O Abort action. When an ioAbort is triggered, the SynqNet node's outputs are disabled (set to the power-on condition) and all axes on motion supervisors associated with the node are aborted and enter the error state. When the I/O Abort conditions are cleared, the states of the axes may be cleared with a call to `mpiMotionAction(..., MPIActionRESET)`. The IoAbort is triggered when any one or more of the following enabled configurations occur.

synqLost	Occurs when a SynqNet node drops out of SYNQ (cyclic) mode to SYNQ_LOST mode. See MEISqNodeConfigTrigger .
nodeDisable	An input bit to the SynqNet node. The node disable circuit is node specific, but is intended to shutdown the node via the IoAbort. See MEISqNodeConfigTrigger .
powerFault	An input bit to the SynqNet node. The power fault circuit is node specific, but is usually connected to an analog power monitor. Typically, when the DAC power or other analog component power is either too high or drops below a threshold, the power fault is triggered. Please see the node/drive manufacturer's documentation for details. See MEISqNodeConfigTrigger .
userFault	A user configurable trigger condition. A value of TRUE enables the trigger, FALSE disables the trigger.

See Also

[meiSqNodeConfigGet](#) | [meiSqNodeConfigSet](#) | [mpiMotionAction](#)

MEISqNodeConfigAlarm

Definition

```
typedef struct MEISqNodeConfigAlarm {
    unsigned long    mask; /* One bit per drive/motor. Triggered by
                               the MEIMotorDedicatedInAMP_FAULT input. */
    long            notCyclicEnable; /* allow nodeAlarm to be asserted
                                         when the node is not in cyclic mode */
    long            ioAbortEnable; /* allow ioAbort to assert nodeAlarm */
} MEISqNodeConfigAlarm;
```

Description

MEISqNodeConfigAlarm specifies the input trigger for the SynqNet node alarm output. The input triggers are the MEIMotorDedicatedInAMP_FAULT bits for each motor/drive interface.

mask	Each bit in the mask represents a motor or drive interface. For example, a value of 0x3 will trigger the node alarm output when either motor 0's OR motor 1's MEIMotorDedicatedInAMP_FAULT bit is TRUE.
notCyclicEnable	This Boolean variable is used to specify whether or not a node can receive an alarm when it is not in cyclic mode. TRUE = node alarm can be asserted in any mode. FALSE = node alarm can only be asserted in cyclic mode.
ioAbortEnable	This Boolean variable is used to specify the effect an I/O abort will have on the node alarm output. TRUE = an I/O abort will trigger a node alarm. FALSE = an I/O abort will not necessarily trigger a node alarm.

See Also

[meiSqNodeConfigGet](#) | [meiSqNodeConfigSet](#)

MEISqNodeConfigPacketError

Definition

```
typedef struct MEISqNodeConfigPacketError {  
    long faultLimit;    /* 0 - 255 */  
    long failLimit;    /* 0 - 255 */  
} MEISqNodeConfigPacketError;
```

Description

MEISqNodeConfigPacketError specifies the limit conditions for SynqNet node packet rate errors.

faultLimit	Packet error rate limit to generate a fault. When the faultLimit is reached, the node will attempt to recover by switching the port used for data transmission. Valid range is 0 to 255. The value saturates at 255.
failLimit	Packet error rate limit to generate a failure. When the failLimit is reached, the node will drop to the SYNQ_LOST state and disable its outputs. Valid range is 0 to 255. The value saturates at 255.

See Also

[meiSqNodeConfigGet](#) | [meiSqNodeConfigSet](#)

MEISqNodeConfigTrigger

Definition

```
typedef struct MEISqNodeConfigTrigger {  
    long    enable;  
    long    invert;  
} MEISqNodeConfigTrigger;
```

Description

MEISqNodeConfigTrigger specifies trigger configurations.

enable	Enables or disables the trigger. A value of TRUE enables the trigger, FALSE disables the trigger.
invert	Normal or inverted trigger polarity. A value of FALSE indicates normal polarity, TRUE indicates inverted polarity.

See Also

[MEISqNodeConfigIoAbort](#)

MEISqNodeConfigUserFault

Definition

```
typedef struct MEISqNodeConfigUserFault {
    long          *addr;    /* firmware addr */
    unsigned long  mask;
    unsigned long  pattern;
} MEISqNodeConfigUserFault;
```

Description

MEISqNodeConfigUserFault specifies the trigger conditions for a user defined input. The trigger condition can be configured for any controller address. When the masked value at the specified addr matches the pattern, the user fault is active. The user fault triggers a SynqNet node IoAbort if the userFault flag in MEISqNodeConfigIoAbort{} is enabled. The user fault also triggers an action for all the motors associated with the node. The userFaultAction is specified in the MEIMotorConfig{} structure.

*addr	A pointer to a controller address.
mask	A bit mask ANDed with the value at the controller address.
pattern	A bit pattern compared to the masked value at the controller address. When the masked value equals the pattern, the user trigger is TRUE.

See Also

[MEISqNodeConfigIoAbort](#) | [MEIMotorConfig](#) | [meiSqNodeConfigGet](#) | [meiSqNodeConfigSet](#)

MEISqNodeDataSize

Definition

```
typedef enum MEISqNodeDataSize { /* read/write data width */
    MEISqNodeDataSize8BIT,
    MEISqNodeDataSize16BIT,
    MEISqNodeDataSize24BIT,
    MEISqNodeDataSize32BIT,
} MEISqNodeDataSize
```

Description

MEISqNodeDataSize is an enumeration of service command data lengths. The data length is in units of bits.

MEISqNodeDataSize8BIT	8 bit data length
MEISqNodeDataSize16BIT	16 bit data length
MEISqNodeDataSize24BIT	24 bit data length
MEISqNodeDataSize32BIT	32 bit data length

See Also

[meiSqNodeCommand](#) | [MEISqNodeCmdHeader](#)

MEISqNodeDownloadParams

Definition

```
typedef struct MEISqNodeDownloadParams {  
    char                *filename;  
    MEISqNodeChannel    channel;  
    MEISqNodeCallback  callback;  
} MEISqNodeDownloadParams;
```

Description

MEISqNodeDownloadParams specifies the parameters for downloading a binary image to a SynqNet node.

*filename	A pointer to a file name. The file contains a header and binary code/data. Files are node/drive specific. Please see the Node Binary Files: Product Table or the drive manufacturer's documentation for the drive binary files.
channel	A communication interface to a node's logic device or drive processor. See MEISqNodeChannel .
callback	A pointer to a callback function, to monitor the download progress. See MEISqNodeCallback .

See Also

[meiSqNodeDownload](#)

MEISqNodeDriveInfo

Definition

```
typedef struct MEISqNodeDriveInfo {  
    char    firmwareVersion[MEISqNodeDriveParamMAX_STRING_LENGTH];  
} MEISqNodeDriveInfo;
```

Description

MEISqNodeDriveInfo contains information about a specified drive.

firmwareVersion
A string containing drive firmware version information that is retrieved from the Drive Processor on the Node.

See Also

[meiSqNodeDownload](#)

MEISqNodeDriveMonitor

Definition

```
typedef struct MEISqNodeDriveMonitor {  
    MEISqNodeDriveMonitorDataType    type;  
    MEISqNodeDriveMonitorData      data;  
} MEISqNodeDriveMonitor;
```

Description

MEISqNodeDriveMonitor specifies the data to be placed in the monitor field by the drive.

type	The drive data is selected by its type. See MEISqNodeDriveMonitorDataType .
data	The location of the drive data. See MEISqNodeDriveMonitorData .

See Also

[MEISqNodeMonitorValue](#) | [meiSqNodeDriveMonitorConfigGet](#) | [meiSqNodeDriveMonitorConfigSet](#)

MEISqNodeDriveMonitorConfig

Definition

```
typedef struct MEISqNodeDriveMonitorConfig {  
    MEISqNodeDriveMonitor    monitorA;  
    MEISqNodeDriveMonitor    monitorB;  
    MEISqNodeDriveMonitor    monitorC;  
}MEISqNodeDriveMonitorConfig;
```

Description

MEISqNodeDriveMonitorConfig specifies the configuration for the drive monitor fields.

monitorA	configuration for drive monitor A
monitorB	configuration for drive monitor B
monitorC	configuration for drive monitor C

See Also

[MEISqNodeDriveMonitor](#) | [meiSqNodeDriveMonitorConfigGet](#) | [meiSqNodeDriveMonitorConfigSet](#)

MEISqNodeDriveMonitorData

Definition

```
typedef union {  
    long    index;        /* the values for these  
                           parameters are drive specific    */  
    long    address;     /* and can be found in the  
                           appropriate drive modules        */  
} MEISqNodeDriveMonitorData;
```

Description

MEISqNodeDriveMonitorData specifies the location of the monitor data. Drive data can be specified by either an index or an address. The location is drive specific. Please see the drive manufacturer's documentation.

index	A drive specific value to select a monitor data field from a table.
address	A drive specific memory address to select the monitor data.

See Also

[meiSqNodeDriveMonitorConfigGet](#) | [meiSqNodeDriveMonitorConfigSet](#)

MEISqNodeDriveMonitorDataType

Definition

```
typedef enum MEISqNodeDriveMonitorDataType {  
    MEISqNodeDriveMonitorDataTypeINDEX,  
    MEISqNodeDriveMonitorDataTypeADDRESS,  
} MEISqNodeDriveMonitorDataType;
```

Description

MEISqNodeDriveMonitorDataType is an enumeration of monitor data selection types.

MEISqNodeDriveMonitorDataTypeINDEX	Select monitor data using an index to a table.
MEISqNodeDriveMonitorDataTypeADDRESS	Select monitor data using an address.

See Also

[meiSqNodeDriveMonitorConfigGet](#) | [meiSqNodeDriveMonitorConfigSet](#)

MEISqNodeDriveParamCallback

Definition

```
typedef void (*MEISqNodeDriveParamCallback)
             (MEISqNodeDriveParamCallbackType type,
              char *name,
              long number,
              char *value);
```

Description

In the **MEISqNodeDriveParamCallback** structure, the function's pointer type defines a function that can be passed to the `meiSqNodeDriveParamFileSet` function. The `meiSqNodeDriveParamFileSet` function will call this type of function to report progress or warnings. A NULL value for the callback pointer will disable the callback feature.

type	the type of event that caused the callback function to be called.
name	name of the drive parameter.
number	drive parameter index.
value	the value of the drive parameter.

See Also

[meiSqNodeDriveParamFileSet](#)

MEISqNodeDriveParamCallbackType

Definition

```
typedef enum {  
    MEISqNodeDriveParamCallbackTypeCHANGED,  
    MEISqNodeDriveParamCallbackTypeSET_FAILED,  
} MEISqNodeDriveParamCallbackType;
```

Description

The **MEISqNodeDriveParamCallbackType** enumeration is used by the `MEISqNodeDriveParamCallback` function to describe the type of event that caused the callback function to be called.

MEISqNodeDriveParamCallbackTypeCHANGED	This indicates that the new drive parameter value is different to the current parameter value.
MEISqNodeDriveParamCallbackTypeSET_FAILED	Setting this drive parameter failed.

See Also

[MEISqNodeDriveParamCallback](#)

MEISqNodeFeedbackSecondary

Definition

```
typedef struct MEISqNodeFeedbackSecondary {  
    long    motorIndex;  
} MEISqNodeFeedbackSecondary;
```

Description

MEISqNodeFeedbackSecondary allows for configuration of the secondary feedback resources on a SynqNet node.

motorIndex
Indicates motorIndex on the node to which the secondary feedback resource is mapped. This value is MEISqNodeNOT_AVAILABLE if the secondary feedback resource does not exist on the node hardware

See Also

[MEISqNodeConfig](#)

MEISqNodeFilename

Definition

```
typedef struct MEISqNodeFileName{  
    char fileName[MEISqNodeFILENAME\_MAX];  
}MEISqNodeFileName;
```

Description

MEISqNodeFilename is used in methods that retrieve filenames from the MPI.

fileName	String containing the name of an SqNode image file.
-----------------	---

See Also

MEISqNodeFpgaType

Definition

```
typedef enum MEISqNodeFpgaType {  
    MEISqNodeFpgaTypeBOOT,  
    MEISqNodeFpgaTypeRUN_TIME,  
} MEISqNodeFpgaType
```

Description

MEISqNodeFpgaType is an enumeration of FPGA types.

MEISqNodeFpgaTypeBOOT	The FPGA is operating with a boot image. The boot image only supports basic SynqNet communication. Use <code>meiSqNodeDownload(.)</code> to download the runtime image to the SynqNet node.
MEISqNodeFpgaTypeRUN_TIME	The FPGA is operating with a runtime image.

See Also

[meiSqNodeInfo](#) | [MEISqNodeInfoFpga](#) | [meiSqNodeDownload](#)

MEISqNodeInfo

Definition

```
typedef struct MEISqNodeInfo {
    long          motorCount;
    long          driveCount;
    long          motorOffset;
    long          feedbackSecondaryCount;
    MEISqNodeInfoId    id;
    MEISqNodeInfoFpga fpga;
    MEISqNodeInfoNetwork network;
    MEISqNodeInfoIo    io;
} MEISqNodeInfo;
```

Description

MEISqNodeInfo contains static data stored for the SynqNet node. The motor objects are indexed sequentially across all the SynqNet nodes associated with each network. Each motor on a controller has a unique number.

motorCount	The number of motors that the SynqNet node supports.
driveCount	The number of drives interfaces that the SynqNet node supports.
motorOffset	The starting number for the first motor on the SynqNet node.
feedbackSecondaryCount	The number of auxillary feedbacks on the node.
id	A structure that contains identification data for the SynqNet node. See MEISqNodeInfoId .
fpga	A structure that contains identification data for the SynqNet node FPGA. See MEISqNodeInfoFpga .
network	A structure that contains network interface information for the SynqNet node. See MEISqNodeInfoNetwork .
io	A structure that returns how many of each type of node I/O this node supports.

See Also

[meiSqNodeInfo](#)

MEISqNodeInfoId

Definition

```
typedef struct MEISqNodeInfoId {
    unsigned long   nodeType;    /* product/mfg code */
    char            *nodeName;   /* product/mfg string */
    unsigned long   option;       /* product option code*/
    unsigned long   switchId;    /* rotary switch id */
    unsigned long   unique;      /* unique id code */

    long            exactMatch; /* TRUE/FALSE */

    char            serialNumber[MEISqNodeID\_CHAR\_MAX];
    char            modelName[MEISqNodeID\_CHAR\_MAX];
    char            manufacturerData[MEISqNodeManufacturerDATA\_CHAR\_MAX];
} MEISqNodeInfoId;
```

Description

MEISqNodeInfoId contains identification data for the SynqNet node.

All nodes by all manufacturers will have **nodeType** and **unique** numbers that should generate a unique identification for each node on the SynqNet network.. Although some node manufacturers may opt to leave the **serialNumber** and **modelName** fields blank, you can still identify and distinguish a node by comparing the **nodeType** and **unique** numbers. The **nodeType** number is also represented by a unique text string *nodeName*.

nodeType	A 32 bit value that identifies the node hardware. The upper 16 bits represent the manufacturer of the SynqNet node hardware. Each manufacturer has a unique value. The lower 16 bits represent the SynqNet node product type. The SynqNet node manufacturer determines a unique value to track a product series. Typically, the node type value is displayed in hex.
*nodeName	A string that represents the SynqNet nodeType. The nodeName string matches the name of the SqNodeLib node specific header file.
option	The product option code within a product series.
switchId	If a node/drive have an physical address switch on its faceplate, switchId will contain the value to which the switch is set. If an ID switch is not supported by a node, this value will be set to -1 (0xFFFFFFFF).

unique	<p>A 32 bit value that identifies the node. It is an unsigned long. The SynqNet node manufacturer determines this unique value to track a single product. This is useful to determine when individual nodes of the same type are switched or replaced on a SynqNet network.</p> <p>NOTE: It is possible for a manufacturer to use the same unique identification number for two nodes of different models. The combination of SqNode.Name (or nodeType) and SqNode.UniqueId will be unique for any given code.</p>
exactMatch	<p>A string that tells you if the node is running under a matched or unmatched classification. The value of meiSqNodeInfo.id.exactMatch is TRUE when all ID components have been matched to a supported configuration. The value is FALSE when running with a default (unmatched) configuration.</p>
serialNumber	<p>A string that represents the SynqNet node serial number. For a given node type, the serial number is unique. The SynqNet node manufacturer determines the serial number to track an individual unit.</p>
modelNumber	<p>A string that represents the SynqNet node model number. The SynqNet node manufacturer determines the model number.</p>
manufacturerData	<p>A string containing Manufacturer-specific data which is stored on the node at time of production.</p>

See Also

[meiSqNodeInfo](#) | [MEISqNodeInfoFpga](#)

MEISqNodeInfoIo

Definition

```
typedef struct MEISqNodeInfoIo {
    long    digitalInCount ;
    long    digitalOutCount ;
    long    analogInCount ;
    long    analogOutCount ;
    long    segmentCount ;
    long    maxWait ;
} MEISqNodeInfoIo;
```

Change History: Modified in the 03.02.00

Description

MEISqNodeInfoIo lists the number of digital and analog inputs that are supported by a SynqNet node.

digitalInCount	The number of digital inputs on a SynqNet node.
digitalOutCount	The number of digital outputs on a SynqNet node.
analogInCount	The number of analog inputs on a SynqNet node.
analogOutCount	The number of analog outputs on a SynqNet node.
segmentCount	The total number of segments on a SynqNet node.
maxWait	This is the maximum amount of time between when the output bit is set in software and the hardware state takes effect.

See Also

[meiSqNodeInfo](#) | [meiSqNodeSegmentDigitalOutGet](#) |
[meiSqNodeSegmentDigitalOutSet](#) | [meiSqNodeSegmentAnalogOutGet](#) |
[meiSqNodeSegmentAnalogOutSet](#)

MEISqNodeInfoFpga

Definition

```
typedef struct MEISqNodeInfoFpga {
    MEISqNodeFpgaType      type;
    unsigned long          vendorDevice;
    unsigned long          version;
    unsigned long          branchVersion;
    long                   defaultVersion; /* TRUE/FALSE */
} MEISqNodeInfoFpga;
```

Description

MEISqNodeInfoFpga contains identification data for the SynqNet node FPGA.

type	The FPGA type. See MEISqNodeFpgaType .
vendorDevice	A 32 bit value that identifies the FPGA image. The upper 16 bits represent the manufacturer of the SynqNet node network interface device. Each manufacturer has a unique vendor value. The lower 16 bits represent the SynqNet node network interface component. The device is typically an FPGA (could be an ASIC). If the device is an FPGA, the vendorDevice information is stored in the FPGA binary image. Each device for a particular vendor has a unique device value. Typically, the vendorDevice value is displayed in hexadecimal format.
version	<p>A 32-bit value that represents the revision of the device.</p> <p>The upper 16 bits (SqMac Version), represent the SynqNet network interface revision.</p> <p>The lower 16 bits (Node Version), represent the device revision.</p> <p>Typically, the version value is displayed in hexadecimal format.</p> <p>Ex: 0x02400344</p> <p>SqMac Version: 0240 Node Version: 0344</p>

branchVersion	<p>A 32-bit value that identifies the branch from an existing version (MajorMinor) or from another Branch.</p> <p>The upper 16 bits (SqMac Branch Version), represent the SynqNet network interface branch revision.</p> <p>The lower 16 bits (Node Branch Version), represent the device branch revision.</p> <p>Ex: 0x01010102</p> <p>SqMac Branch Version: 0101 Node Branch Version: 0102</p>
defaultVersion	<p>Indicates if the default version of the SqNode FPGA image is loaded on this node. The defaultVersion defines the version of the SynqNet node FPGA image that was built and tested with the current version of the MPI.</p>

See Also

[meiSqNodeInfo](#) | [MEISqNodeInfo](#) | [MPI/SynqNet FPGA Compatibility Check](#)

MEISqNodeInfoNetwork

Definition

```
typedef struct MEISqNodeInfoNetwork {
    long    number ;
    long    inPorts ;
    long    outPorts ;
} MEISqNodeInfoNetwork ;
```

Description

MEISqNodeInfoNetwork structure contains information about the SynqNet node's network interface.

Remarks

The labeling convention for IN and OUT ports is for convenience. The hardware ports are identical. During SynqNet initialization, the node are discovered based on the OUT to IN port connections.

number	An index to a SynqNet network associated with a controller.
inPorts	The number of SynqNet IN port network interfaces.
outPorts	The number of SynqNet OUT port network interfaces.

See Also

[meiSqNodeInfo](#)

MEISqNodeMemory

Definition

```
typedef enum MEISqNodeMemory {  
    MEISqNodeMemoryDATA,      /* node/drive processor RAM */  
    MEISqNodeMemoryPROGRAM,   /* drive processor program memory */  
    MEISqNodeMemoryIO,       /* drive I/O memory */  
    MEISqNodeMemoryDRIVE,     /* direct command to drive */  
} MEISqNodeMemory;
```

Description

MEISqNodeMemory is an enumeration of drive region types to access with a service command.

MEISqNodeMemoryDATA	node/drive processor data memory
MEISqNodeMemoryPROGRAM	drive processor program memory
MEISqNodeMemoryIO	drive I/O memory
MEISqNodeMemoryDRIVE	direct command to drive processor

See Also

[MEISqNodeCmdHeader](#) | [meiSqNodeCommand](#)

MEISqNodeMessage

Definition

```
typedef enum {
    MEISqNodeMessageINVALID,
    MEISqNodeMessageNODE_INVALID,
    MEISqNodeMessageCONFIG_NETWORK_MISMATCH,
    MEISqNodeMessageMAP_CONFIG_MISMATCH,
    MEISqNodeMessageNOT_IN_CONFIG_FILE,
    MEISqNodeMessageCONFIG_FILE_FORMAT_INVALID,

    MEISqNodeMessageRESPONSE_TIMEOUT,
    MEISqNodeMessageREADY_TIMEOUT,
    MEISqNodeMessageSRVC_ERROR,
    MEISqNodeMessageSRVC_UNSUPPORTED,
    MEISqNodeMessageSRVC_CHANNEL_INVALID,

    MEISqNodeMessageCMD_NOT_SUPPORTED,
    MEISqNodeMessageDISCOVERY_FAILURE,
    MEISqNodeMessageDISPATCH_ERROR,
    MEISqNodeMessageINIT_FAILURE,
    MEISqNodeMessageINTERFACE_ERROR1,
    MEISqNodeMessageFILE_NODE_MISMATCH,
    MEISqNodeMessageFILE_INVALID,
    MEISqNodeMessageINVALID_HEADER,
    MEISqNodeMessageDOWNLOAD_FAIL,
    MEISqNodeMessageVERIFY_FAIL,
    MEISqNodeMessageDOWNLOAD_NOT_SUPPORTED,
    MEISqNodeMessageVERIFY_NOT_SUPPORTED,
    MEISqNodeMessageBOOT_ROM_INVALID,
    MEISqNodeMessageINVALID_TABLE,
    MEISqNodeMessageINVALID_STR_LEN,
    MEISqNodeMessageFEEDBACK_MAP_INVAILD,
    MEISqNodeMessageNODE_FAILURE,

    MEISqNodeMessageIO_MODULE_INCOMPATIBILITY,
    MEISqNodeMessageIO_MODULE_EEPROM_NOT_PROGRAMMED,
    MEISqNodeMessageIO_MODULE_COUNT_EXCEEDED,
    MEISqNodeMessageIO_MODULE_LENGTH_CHECK_FAILED,
    MEISqNodeMessageIO_MODULE_3_3V_BUS_CURRENT_EXCEEDED,
    MEISqNodeMessageIO_MODULE_24V_BUS_CURRENT_EXCEEDED,

    MEISqNodeMessageIO_SLICE_INITIALIZATION_ERROR,
    MEISqNodeMessageIO_SLICE_INITIALIZATION_TIMEOUT,
    MEISqNodeMessageIO_SLICE_TOPOLOGY_MISMATCH,

    MEISqNodeMessageBOOT_FILE_NOT_FOUND,
    MEISqNodeMessagePARAM_READ_ONLY,
    MEISqNodeMessagePARAM_LOCKED,
}
```

```

    MEISqNodeMessageMONITOR_INDEX ,
    MEISqNodeMessageMONITOR_ADDRESS ,
} MEISqNodeMessage ;

```

Required Header: stdmei.h

Change History: Modified in the 03.02.00

Description

MEISqNodeMessage is an enumeration of SynqNet node error messages that can be returned by the MPI library.

MEISqNodeMessageINVALID

The SqNode type is out of range. This message code is returned by SynqNet node methods if the node type is not a member of the SQNodeLibNodeType enumeration.

MEISqNodeMessageNODE_INVALID

The SynqNet Node number is out of range. This message code is returned if the given node number is less than zero, or greater than or equal to MEISynqNetMaxNODE_COUNT.

MEISqNodeMessageCONFIG_NETWORK_MISMATCH

The type of map file specified in meiSqNodeDriveParamFileSet does not match the type of drive found on the network.

MEISqNodeMessageMAP_CONFIG_MISMATCH

The parameter name or number specified in meiSqNodeDriveMapParamFileSet was not valid for the specified drive.

MEISqNodeMessageNOT_IN_CONFIG_FILE

The parameter name or number specified in meiSqNodeDriveMapParamFileSet was not found.

MEISqNodeMessageCONFIG_FILE_FORMAT_INVALID

A file with an incorrect format was used in meiSqNodeDriveMapParamFileSet.

MEISqNodeMessageRESPONSE_TIMEOUT

Currently unused and is reserved for future use.

MEISqNodeMessageREADY_TIMEOUT

Currently unused and is reserved for future use.

MEISqNodeMessageSRVC_ERROR

Currently unused and is reserved for future use.

MEISqNodeMessageSRVC_UNSUPPORTED

Currently unused and is reserved for future use.

MEISqNodeMessageSRVC_CHANNEL_INVALID

Invalid service channel specified. See [MEISqNodeCmdHeader](#).

MEISqNodeMessageCMD_NOT_SUPPORTED

The service command is not supported by the node.

MEISqNodeMessageDISCOVERY_FAILURE

Unable to discover node resources.

MEISqNodeMessageDISPATCH_ERROR

Is the default error code returned when a node specific routine has failed. Check the node FPGA version to verify whether or not it is correct.

MEISqNodeMessageINIT_FAILURE

A node specific initialization routine was unable to successfully complete its routine. Verify that the node FPGA is the default version for your MPI version. See [MEISqNodeInfoFpga.defaultVersion](#).

MEISqNodeMessageINTERFACE_ERROR1

This is an outdated node, which does not support the current discovery routine.

MEISqNodeMessageFILE_NODE_MISMATCH

Node type does not match the file provided for download.

MEISqNodeMessageFILE_INVALID

The file provided for download was not found or was corrupted.

MEISqNodeMessageINVALID_HEADER

The header information in the download image is invalid. Please verify firmware file to be correct and retry download. If firmware file is correct please contact firmware manufacturer.

MEISqNodeMessageDOWNLOAD_FAIL

Node firmware download failed. Verify that the firmware file is correct and retry the download.

NOTE: A network reset may be required.

MEISqNodeMessageVERIFY_FAIL

The node FPGA firmware does not match the FPGA image file.

MEISqNodeMessageDOWNLOAD_NOT_SUPPORTED

The downloading of the node firmware (FPGA) image is not supported for this node.

MEISqNodeMessageVERIFY_NOT_SUPPORTED

The Node specified for verification does not support the upload of the FPGA image. Therefore, the image cannot be verified.

MEISqNodeMessageBOOT_ROM_INVALID

The SqNode Boot Rom identification or version is not recognized by the MPI.

MEISqNodeMessageINVALID_TABLE

Invalid resource table in node module. This is a fatal error within the MPI. Please verify MPI and node FPGA versions to be correct and then contact MEI's Technical Support.

MEISqNodeMessageINVALID_STR_LEN

An attempt to write information to the node has failed due to an invalid string length.

MEISqNodeMessageFEEDBACK_MAP_INVAILD

Returned from MEISqNodeConfigSet(...) when the given secondary encoder (n) is not mappable to the motor on the node specified by MEISqNodeFeedbackSecondary[n].motorIndex.

MEISqNodeMessageNODE_FAILURE

An attempt was made to access a SynqNet node that has a node failure event active. [SynqNet Node Failure](#) describes the details.

MEISqNodeMessageIO_MODULE_INCOMPATIBILITY

Two modules attached to a SQID node are incompatible. This error message code is returned when initializing a SQID node. Different types of I/O module may be incompatible and will not work on the same SQID node.

MEISqNodeMessageIO_MODULE_EEPROM_NOT_PROGRAMMED

The EEPROM on one of the modules attached to a SQID node has not been programmed.

MEISqNodeMessageIO_MODULE_COUNT_EXCEEDED

The maximum number of I/O that can be supported by a SQID node has been exceeded.

MEISqNodeMessageIO_MODULE_LENGTH_CHECK_FAILED

During the intialization of the modules attached to a SQID node, the length of at least one of the inter module buses did not match the length calculated from data in the module EEPROMs.

MEISqNodeMessageIO_MODULE_3_3V_BUS_CURRENT_EXCEEDED

During the initialization of the modules attached to a SQID node, the maximum current that can be drawn from the inter module 3.3V bus exceeds the allowable current.

MEISqNodeMessageIO_MODULE_24V_BUS_CURRENT_EXCEEDED

During the initialization of the modules attached to a SQID node, the maximum current that can be drawn from the inter module 5V bus exceeds the allowable current.

MEISqNodeMessageIO_SLICE_INITIALIZATION_ERROR

An error was encountered while initializing the slice node.

MEISqNodeMessageIO_SLICE_INITIALIZATION_TIMEOUT

The slice node did not initialize within the expected time.

MEISqNodeMessageIO_SLICE_TOPOLOGY_MISMATCH

The slices attached to the network adapter are different than the stored/expected arrangement of slices.

MEISqNodeMessageBOOT_FILE_NOT_FOUND

The boot file "kollmorgen_ember.a00" was not found. When downloading drive images to Kollmorgen CD, DASA, and PicoDAD drives, a boot file is downloaded to the drive prior to the actual drive image. This boot file needs to be located in the same directory as the drive's image file that is provided for download.

MEISqNodeMessagePARAM_READ_ONLY

The drive parameter that the user is attempting to set is read only.

MEISqNodeMessagePARAM_LOCKED

The drive parameter that the user is attempting to set is not accessible. SelSFDParam must be set to 0, otherwise the SFD motor parameters will be used.

MEISqNodeMessageMONITOR_INDEX

Drive does not support the configuring of Monitors through indexing.

MEISqNodeMessageMONITOR_ADDRESS

Drive does not support the configuring of Monitors through addressing.

See Also

[meISqNodeDriveMapParamFileSet](#) | [meISqNodeConfigSet](#)

MEISqNodeMonitorValue

Definition

```
typedef struct MEISqNodeMonitorValue {  
    long    count;  
    long    monitor[MEISqNodeMonitorValueIndexLAST];  
} MEISqNodeMonitorValue;
```

Description

MEISqNodeMonitorValue contains the data for the monitor fields read by the `meiSqNodeDriveMonitor(...)` method.

count	The number of monitor fields read. This specifies the size of the monitor array.
monitor	An array of monitor data fields. Each field is indexed by the <code>MEISqNodeMonitorValueIndex</code> enumeration.

See Also

[meiSqNodeDriveMonitor](#) | [meiSqNodeDriveMonitorConfigGet](#) | [meiSqNodeDriveMonitorConfigSet](#)

MEISqNodeMonitorValueIndex

Definition

```
typedef enum MEISqNodeMonitorValueIndex {  
    MEISqNodeMonitorValueIndexA,  
    MEISqNodeMonitorValueIndexB,  
    MEISqNodeMonitorValueIndexC,  
    MEISqNodeMonitorValueIndexD,  
} MEISqNodeMonitorValueIndex;
```

Description

MEISqNodeMonitorValueIndex is an enumeration of indices to node monitor values.

MEISqNodeMonitorValueIndexA	Index to node monitor value A.
MEISqNodeMonitorValueIndexB	Index to node monitor value B.
MEISqNodeMonitorValueIndexC	Index to node monitor value C.
MEISqNodeMonitorValueIndexD	Index to node monitor value D.

See Also

[meISqNodeDriveMonitor](#) | [meISqNodeDriveMonitorConfigGet](#) | [meISqNodeDriveMonitorConfigSet](#)

MEISqNodeResponse

Definition

```
typedef struct MEISqNodeResponse {  
    unsigned long    data;    /* response data */  
} MEISqNodeResponse;
```

Description

MEISqNodeResponse contains the service command response data.

data	The response information from a service command. The data field is only valid for MEISqNodeCmdTypeREAD command types.
-------------	---

See Also

[meiSqNodeCommand](#)

MEISqNodeSegmentInfo

Definition

```
#define MEISqNodeSegmentInfoSERIAL_NUMBER_LENGTH 0x20
#define MEISqNodeSegmentInfoMODEL_NAME_LENGTH 0x20
#define MEISqNodeSegmentInfoMANUFACTURER_LENGTH 0x10

typedef struct MEISqNodeSegmentInfo {
    long    id;
    long    option;
    char    serialNumber[MEISqNodeSegmentInfoSERIAL_NUMBER_LENGTH];
    char    modelName[MEISqNodeSegmentInfoMODEL_NAME_LENGTH];
    long    digitalInCount;
    long    digitalOutCount;
    long    analogInCount;
    long    analogOutCount;
    long    version;
    long    paramCount;
    long    memoryCount;
    char    manufacturerData[MEISqNodeManufacturerDATA_CHAR_MAX];
} MEISqNodeSegmentInfo;
```

Change History: Added in the 03.02.00

Description

MEISqNodeSegmentInfo contains data about the I/O that is supported by a segment (slice or module) attached to a SynqNet node.

id	This field contains a 32-bit number that uniquely identifies this kind of segment. For modules attached to a SQID node, the top 16 bits are the manufacturer code and the bottom 16 bits are to product code.
option	The option code for the segment. For slices attached to a Slice network adaptor this field is always zero.
serialNumber	The serial number of this segment .
modelName	A text string giving the model name of this module. For slices attached to a Slice network adaptor, this field is always a null string.

digitalInCount	The total number of digital inputs on this segment.
digitalOutCount	The total number of digital outputs on this segment.
analogInCount	The total number of analog inputs on this segment.
analogOutCount	The total number of analog outputs on this segment.
version	The version of the segment. For modules attached to a SQID node, this field is always zero.
paramCount	The total number segment parameters supported by this segment. For modules attached to a SQID node this field is always zero.
memoryCount	The total number of memory bytes available on this segment. For modules attached to a SQID node, this field is always zero.
manufacturerData	A series of characters programmed into the node during manufacturing. For slices attached to a Slice network adaptor, this field is always zero.

See Also

[MEISqNodeConfigloAbort](#)

MEISqNodeSegmentUserData

Definition

```
typedef struct MEISqNodeSegmentUserData {  
    char    data[MEISqNodeSegmentUserData\_CHAR\_MAX];  
} MEISqNodeSegmentUserData;
```

Change History: Modified in the 03.02.00

Description

Modules attached to a SQID node have a small section of non-volatile memory that can be used for any purpose by the user. The **MEISqNodeSegmentUserData** structure holds a copy of this data.

data	Up to 16 bytes of data.
-------------	-------------------------

See Also

[meiSqNodeSegmentUserDataGet](#) | [meiSqNodeSegmentUserDataSet](#) | [MPI Overview I/O: User Data](#)

MEISqNodeStatus

Definition

```
typedef struct MEISqNodeStatus {
    MEISqNodeStatusPacketError    upStreamError ;
    MEISqNodeStatusPacketError    downStreamError ;
    MEISqNodeStatusCrcError       crcError ;
    MPIEventMask                  eventMask ;
} MEISqNodeStatus ;
```

Description

MEISqNodeStatus contains error counters and the ***eventMask*** for a SynqNet node.

upStreamError	The rate and count of bad synqNet messages received by the controller from the Node. See MEISqNodeStatusPacketError .
downStreamError	The rate and count of bad synqNet messages received by the Node from the controller. See MEISqNodeStatusPacketError .
crcError	Counters for the CRC errors. See MEISqNodeStatusCrcError .
eventMask	Array that defines the event mask bits. The array is defined as: <pre>typedef MPIEventMaskeLEMENT_TYPE MPIEEventMask [MPIEventMaskeLEMENTS]</pre> The bits are defined by the MPI/MEIEventType enumerations.

See Also

[meiSqNodeStatus](#) | [meiSynqNetStatus](#) | [MEISqNodeConfig](#)

MEISqNodeStatusCrcError

Definition

```
typedef struct MEISqNodeStatusCrcError {  
    long    port[MEINetworkPortLAST];  
} MEISqNodeStatusCrcError;
```

Description

MEISqNodeStatusCrcError contains CRC error counters for each network port. The CRC error counters are helpful for diagnosing data integrity problems. The counter increments for any CRC error on any packet received at that port (whether the packet is addressed to the node or not). The CRC error counters are cleared during network initialization.

port	An array of CRC error counters. Each network port has one CRC error counter. The valid range is 0 to 255. The value saturates at 255.
-------------	---

See Also

[meiSqNodeStatus](#) | [MEINetworkPort](#)

MEISqNodeStatusPacketError

Definition

```
typedef struct MEISqNodeStatusPacketError {  
    long    rate;  
    long    count;  
} MEISqNodeStatusPacketError;
```

Description

MEISqNodeStatusPacketError contains packet error counters and rate counters. Each SynqNet node has a packet error counter and a packet error rate counter. Packets addressed to a node are checked for integrity.

The packet error counters are used to monitor long-term data integrity. These counters do not trigger any fault or fail actions. The packet error counter is incremented once for each missing or invalid packet. Typically, an application will periodically read the packet error counters and store the values in a log.

The packet error rate counters are used to trigger fault recovery and/or failure shutdown. The packet error rate counter is incremented for each missing or invalid packet and is decremented for 16 consecutive valid packets. Thus, the packet error rate counters can detect large errors over short periods of time or small errors over long periods of time.

rate	The packet error rate counter. The valid range is 0 to 255. The value saturates at 255.
count	The packet error counter. The valid range is 0 to 255. The value saturates at 255.

See Also

[meiSqNodeStatus](#) | [MEISqNodeConfigPacketError](#)

MEISqNodeUserData

Definition

```
typedef struct MEISqNodeUserData {  
    char    data[MEISqNodeUserData\_CHAR\_MAX];  
}MEISqNodeUserData ;
```

Change History: Modified in the 03.02.00

Description

MEISqNodeUserData is used to store the user information that is located on the SqNode.

data	User information on the SqNode used for storing SqNode identification or any other useful data. Programmable string to be used by a customer to store identification-specific information. This data is not used by the MPI and is stored in the SqNode's EEPROM.
-------------	---

See Also

[meiSqNodeUserDataGet](#) | [meiSqNodeUserDataSet](#)

MEISqNodeID_CHAR_MAX

Definition

```
#define MEISqNodeID_CHAR_MAX (30)
```

Description

MEISqNodeID_CHAR_MAX defines the maximum length (number of characters) in a sqNode identification string.

See Also

MEISqNodeFILENAME_MAX

Definition

```
#define MEISqNodeFILENAME_MAX (18)
```

Description

MEISqNodeFILENAME_MAX defines the maximum size allowed for SqNode filenames.

See Also

MEISqNodeManufacturerDATA_CHAR_MAX

Definition

```
#define MEISqNodeManufacturerDATA_CHAR_MAX (0x10)
```

Description

MEISqNodeManufacturerDATA_CHAR_MAX defines the maximum number of characters stored in the Manufacturer's Data field.

See Also

MEISqNodeMaxFEEDBACK_SECONDARY

Definition

```
#define MEISqNodeMaxFEEDBACK_SECONDARY (MEISqNodeMaxMOTORS)
```

Description

MEISqNodeMaxFEEDBACK_SECONDARY defines the maximum number of secondary feedback devices per SynqNet node.

See Also

[MEISqNodeConfig](#) | [MEISqNodeFeedbackSecondary](#)

MEISqNodeMaxMOTORS

Definition

```
#define MEISqNodeMaxMOTORS (MEIXmpMotorsPerBlock)
```

Description

MEISqNodeMaxMOTORS defines the maximum number of motor objects supported on a single SynqNet node. This define should be used instead of the `MEIXmpMotorsPerBlock` definition in `xmp.h`. It is recommended that applications avoid programming to defines or structures in `xmp.h`

See Also

[SqNode Objects](#)

MEISqNodeNOT_AVAILABLE

Definition

```
#define MEISqNodeNOT_AVAILABLE (-1)
```

Description

MEISqNodeNOT_AVAILABLE defines a possible value for `MEISqNodeConfig.feedbackSecondary[n].motorIndex`.
If `motorIndex = MEISqNodeNOT_AVAILABLE`, then a secondary feedback device does not exist on the hardware.

See Also

[MEISqNodeConfig](#) | [MEISqNodeFeedbackSecondary](#)

MEISqNodeSTATUS_NOT_AVAILABLE

Definition

```
#define MEISqNodeSTATUS_NOT_AVAILABLE (-1)
```

Description

With exception to `MEISqNodeStatus.eventMaskValue`, the **MEISqNodeSTATUS_NOT_AVAILABLE** value is assigned to all Node status variables when the Status is not available as a result of lost communication with the node.

See Also

[MEISqNodeStatus](#)

MEISqNodeUserData_CHAR_MAX

Definition

```
#define MEISqNodeUserData_CHAR_MAX (0x10)
```

Description

MEISqNodeUserData_CHAR_MAX defines the maximum number of characters in the User defined string, stored on the SqNode.

See Also

[MEIFpgaSqNodeVersionMAX](#) | [MEIFpgaSqNodeVersionDEFAULT](#) | [MPI/SynqNet FPGA Compatibility Check](#)

MEISqNodeSegmentInfoMANUFACTURER_LENGTH

Definition

```
#define MEISqNodeSegmentInfoMANUFACTURER_LENGTH 0x10
```

Change History: Added in the 03.02.00

Description

MEISqNodeSegmentInfoMANUFACTURER_LENGTH defines the maximum number of bytes in the manufacturer data.

See Also

[Overview of MPI I/O: What Information is Available About Each I/O Segment | meiSqNodeSegmentInfo](#)

MEISqNodeSegmentInfoMODEL_NAME_LENGTH

Definition

```
#define MEISqNodeSegmentInfoMODEL_NAME_LENGTH 0x20
```

Change History: Added in the 03.02.00

Description

MEISqNodeSegmentInfoMODEL_NAME_LENGTH defines the maximum number of characters in the model name description.

See Also

[Overview of MPI I/O: What Information is Available About Each I/O Segment | meiSqNodeSegmentInfo](#)

MEISqNodeSegmentInfoSERIAL_NUMBER_LENGTH

Definition

```
#define MEISqNodeSegmentInfoSERIAL_NUMBER_LENGTH 0x20
```

Change History: Added in the 03.02.00

Description

MEISqNodeSegmentInfoSERIAL_NUMBER_LENGTH defines the maximum number of characters in the serial number.

See Also

[Overview of MPI I/O: What Information is Available About Each I/O Segment | meiSqNodeSegmentInfo](#)

MEISqNodeSegmentUserData_CHAR_MAX

Definition

```
#define MEISqNodeSegmentUserData_CHAR_MAX (0x10)
```

Change History: Added in the 03.02.00

Description

MEISqNodeSegmentUserData_CHAR_MAX defines the maximum number of user data bytes.

See Also

[MEISqNodeSegmentUserData](#) | [MPI Overview I/O: User Data](#)

MEIDriveMapParamMAX_STRING_LENGTH

Declaration

```
#define MEIDriveMapParamMAX_STRING_LENGTH (256)
```

Required Header: stdmpi.h

Description

MEIDriveMapParamMAX_STRING_LENGTH macro defines the maximum length of a string that can be read from or written to a drive parameter.

See Also

MEIFPGARINCONREV

Definition

```
#define MEIFPGARINCONREV (0x0224)
```

Change History: Modified in the 03.02.00

Description

MEIFPGARINCONREV defines the version of the SynqNet controller FPGA image that was built and tested with the current version of the MPI.

See Also

MEIFpgaSqMACVersionDEFAULT

Definition

```
#define MEIFpgaSqMACVersionDEFAULT (0x020E)
```

Description

MEIFpgaSqMACVersionDEFAULT defines the version of the SqMAC FPGA image that was built and tested with the current version of the MPI. The sqMAC FPGA image is built into the SynqNet node FPGA image. This version applies to all node types.

See Also

[MEIFpgaSqNodeVersionDEFAULT](#) | [MPI/SynqNet FPGA Compatibility Check](#)

MEIFpgaSqMACVersionMIN

Definition

```
#define MEIFpgaSqMACVersionMIN    (0x0207)
```

Description

MEIFpgaSqMACVersionMIN defines the minimum version of the SqMAC FPGA image that is compatible with the current version of the MPI. The sqMAC FPGA image is built into the SynqNet node FPGA image.

This version applies to all node types.

See Also

[MEIFpgaSqNodeVersionDEFAULT](#) | [MPI/SynqNet FPGA Compatibility Check](#)

MEIFpgaSqMACVersionMAX

Definition

```
#define MEIFpgaSqMACVersionMAX (0x02FF)
```

Description

MEIFpgaSqMACVersionMAX defines the maximum version of the SqMAC FPGA image that is compatible with the current version of the MPI. The sqMAC FPGA image is built into the SynqNet node FPGA image.

This version applies to all node types.

See Also

[MEIFpgaSqNodeVersionDEFAULT](#) | [MPI/SynqNet FPGA Compatibility Check](#)

MEIFpgaSqNodeVersionDEFAULT

Definition

```
#define MEIFpgaSqNodeVersionDEFAULT (0x0341)
```

Change History: Modified in the 03.02.00

Description

MEIFpgaSqNodeVersionDEFAULT defines the version of the SynqNet node FPGA image that was built and tested with the current version of the MPI. This is the recommended version to have loaded on all SynqNet nodes.

This version may not apply to all node types.

See Also

[MEIFpgaSqNodeVersionMIN](#) | [MEIFpgaSqNodeVersionMAX](#) | [MPI/SynqNet FPGA Compatibility Check](#)

MEIFpgaSqNodeVersionMIN

Definition

```
#define MEIFpgaSqNodeVersionMIN    (0x0303)
```

Description

MEIFpgaSqNodeVersionMIN defines the minimum version of the SynqNet node FPGA image that is compatible with the current version of the MPI.

This version may not apply to all node types.

See Also

[MEIFpgaSqNodeVersionMAX](#) | [MEIFpgaSqNodeVersionDEFAULT](#) | [MPI/SynqNet FPGA Compatibility Check](#)

MEIFpgaSqNodeVersionMAX

Definition

```
#define MEIFpgaSqNodeVersionMAX    (0x03FF)
```

Description

MEIFpgaSqNodeVersionMAX defines the maximum version of the SynqNet node FPGA image that is compatible with the current version of the MPI.

This version may not apply to all node types.

See Also

[MEIFpgaSqNodeVersionMIN](#) | [MEIFpgaSqNodeVersionDEFAULT](#) | [MPI/SynqNet FPGA Compatibility Check](#)